experience

function

quality

style

technology

grab rail manual





Con-Serv® symbols are designed to give assistance to healthcare providers in selecting the most suitable grab rail option for people with disabilities.



CLAM FLANGE™

This symbol confirms the grab rail as represented is manufactured with a pre-formed 78 mm snap on domed cover with a 5 degree radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction. FEATURES & BENEFITS PAGE 28



HYGIENIC SEAL®

This symbol confirms the grab rail as represented is fabricated with Con-Serv's own 50 mm (TPE) fitted flange HYGIENIC SEAL®. The flange is designed with a 5 degree radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction.

FEATURES & BENEFITS PAGE 29



LINEAR

This symbol confirms the grab rail as represented is fabricated with Con-Serv's "T" leg Linear flange. The flange is designed with a 5 degree radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction.

FEATURES & BENEFITS PAGE 43



DIMENSIONAL COMPLIANT

This symbol when exhibited confirms that the item complies with the dimensional requirements of AS 1428.1-2009 for installation where applicable in water closets, 2 walled shower enclosure.



PWD SHOWER COMPLIANT - 2

This symbol when exhibited, confirms that the grab rail handshower kit complies **strictly** with all requirements of AS 1428.1-2009 for a 2 walled shower enclosure for People with Disabilities (PWD).

 $\ensuremath{\mathbb{R}}$ and TM

Indicate trademarks of Con-Serv Corporation Australia Pty Ltd.

OUR PROMISE

Con-Serv Corporation Australia Pty Ltd warrants all products to be free from manufacturing defects for 5 years from date of purchase. Con-Serv will repair or replace defective items if defects occur in normal use. Con-Serv will not be liable for defects arising through normal wear and tear. Item(s) must be returned with proof of purchase to Con-Serv at 17 Glentanna Street, Kedron, Queensland 4031. We will attend to your warranty claim after we make appropriate investigations. Contact our Service Manager during normal office

hours on 1300 467 322 or at our email address of warranty@con-serv.com.au . If a warranty claim is accepted, Con-Serv will bear the

reasonable costs of the return of the defective item(s) to us. A claim for expenses associated with making a claim for a defective product must be in writing and submitted to us with copies of supporting documents. The benefits given under our warranty are in addition to other rights and remedies of the customer under a law in relation to goods and services to which this warranty relates. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or a refund for a major failure and compensation for any other reasonable foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.





Bathrooms	
Bathroom Accessories - Modena Collection	. 2-3
Bathroom Accessories - Comfort Collection	. 4-7
Bathroom Baskets	. 8
Bathroom Rails - 25 mm Comfort Collection	. 9
Shower Systems For Healthcare Applications	
HOSFAB® - Commercial Healthcare Kits	
HOSFAB® - Standard Healthcare Kits	
HOSFAB® - Premium Healthcare Kits	
HOSFAB® - People With Disabilities (PWD) Kits	
Healthcare Kit Accessories	. 26
Grab Rails SAFE-ASSIST® - Regular - Straight Grab Rails	30-31
SAFE-ASSIST® - Regular - Toilet Assist Grab Rails	
SAFE-ASSIST® - Regular - Corner Grab Rails	
SAFE-ASSIST® - Regular - Corner Grab Halls	
SAFE-ASSIST® - Regular - Stronger necess drab halls	
SAFE-ASSIST® - Premium - Toilet Assist Grab Rails	
SAFE-ASSIST® - Premium - Shower Recess Grab Rails	
SAFE-ASSIST® - Premium - Towel Rail / Grab Rail Combination	
SAFE-ASSIST® - Premium - Linear Grab Rail Options	
SAFE-ASSIST® - TILTLOCK® - Lock-Up / Lock-Down Folding Rail-Ways®	
SAFE-ASSIST® - SWINGLOCK® - Side Swing Grab Rail	
SAFE-ASSIST® - Folding Shower Seats	
SAFE-ASSIST® - Backrest Toilet Support Options	
SAFE-ASSIST® - Anti-Ligature Grab Rails	
Rail-Ways® - Accessories	.27
Technical Product Information	
CLAM™ Flange Information Page	28
HYGIENIC SEAL®Information Page	
Circulation Space in Toilets/Water Closets	
Options for Use in Toilets/Water Closets	
Systems for PWD - 2 Walled Shower Enclosure	
Options for Use in 2 Walled Shower Enclosure	
Systems for PWD - To Suit Combined Sanitary Compartment	
Options for PWD - To Suit Combined Sanitary Compartment	
Stainless Steel Information Page	.01

AVAILABILITY

The items shown in this manual are generally exstock. For custom made configuration grab rails, allow 10 working days for fabrication and delivery. Returns and credit facilities are not available for these models.

COPYRIGHT

This document is Standards Australia Ltd copyrighted material that is distributed by SAI Global on Standards Australia Ltd's behalf. It may be reproduced in accordance with the terms of SAI Global Ltd's Licence 1108-c182 to Con-Serv Corporation Australia Pty. Ltd. All licensed copies of this document must be obtained from the Licensee. Standards Australia Ltd's material is not for resale, reproduction or distribution in whole or in part without written permission from SAI Global Ltd: tel +61 2 8206 6355 or copyright@saiglobal.com

 ${\bf CON\text{-}SERV~CORP.~AUSTRALIA~PTY.~LTD.}$

A. B. N. 97 010 372 639


17 Glentanna Street, Kedron Brisbane Qld 4031 Australia Telephone:+61 (0)7 3630 5744 Facsimile:+61 (0)7 3630 5755

E-mail: mail@con-serv.com.au Website: www.con-serv.com.au



BATHROOM ACCESSORIES - 100 SERIES MODENA COLLECTION

A distinctive range of premium accessories.





BATHROOM ACCESSORIES - 100 SERIES MODENA COLLECTION


A distinctive range of premium accessories.

	Code	Finish	Features
BA 108 C - 530 mm X 10 mm CLEAR TEM	BA 108 C	Chrome	530 mm x 10 mm clear tempered glass shelf. Brackets chrome plated brass.
6	BA 729 BO	Spare part Barrier only	530
BA 111 C - HAND TOWEL RAIL			
BA 112 C - PAPER HOLDER	BA 111 C	Chrome	280 mm Ø to Ø wall fixings. Chrome plated brass.
	BA 112 C	Chrome	Chrome plated brass.
BA 114 C - TOILET BRUSH WITH HOLDER			50 174
DA 114 C - TUILET BRUSH WITH HULDER	BA 114 C	Chrome	Brass made wall mounted toilet brush set with frosted glass
			bowl.
BA 115 C - SINGLE ROBE HOOK	BA 115 C	Chrome	Chrome plated brass.
			59 62




DA TOO O TUMBLED HOLDED	Code	Finish	Features
BA 700 C - TUMBLER HOLDER	BA 700 C BA 700 GO	Chrome Spare part Glass only	Chrome plated brass. Frosted glass tumbler
BA 701 C - SOAP DISH HOLDER	BA 701 C	Chrome	Chrome plated brass.
			52 0 130
BA 703 C - TOWEL RING	BA 703 C	Chrome	Chrome plated brass.
BA 704 C - 600 mm - 20 mm SINGLE TOV	WEL RAIL BA 704 C	Chrome	600 mm Ø to Ø wall flange.
8			
BA 705 C - 800 mm - 20 mm SINGLE TOV	WEL RAIL BA 705 C	Chrome	800 mm Ø to Ø wall flange.
8			800 180 = 3150
BA 706 C - 600 mm - 20 mm DOUBLE TO	WEL RAIL BA 706 C	Chrome	600 mm Ø to Ø wall flange.
4 Con-Serv Grab Rail Manual			600 115 500















BATHROOM BASKETS - COMFORT COLLECTION

Select from a range of various depths, rectangle, corner and semi-circular wire basket designs that display strength and creative excellence. Constructed of heavy chrome plated brass. All baskets have innovative concealed fixings.

	Code	Finish	Features
WB 001 - RECTANGULAR BASKET - LARGE	WB 001 C WB 001 CG	Chrome Chrome/Gold	138 85.5
WB 002 - RECTANGULAR BASKET - MEDIU WB 003 - RECTANGULAR BASKET - SMALL	WB 002 C WB 002 CG	Chrome Chrome/Gold	128 65.5
	WB 003 C WB 003 CG	Chrome Chrome/Gold	108 T37.5
WB 004 - OPEN FRONT RECTANGULAR BAS	WB 004 C WB 004 CG	Chrome Chrome/Gold	128 37.5
WB 005 - OPEN FRONT RECTANGULAR BAS	WB 005 C WB 005 CG	Chrome Chrome/Gold	103 37.5
WB 006 - CORNER BASKET WITH HOOK WB 007 - CORNER BASKET - LARGE	WB 006 C WB 006 CG	Chrome Chrome/Gold	206
	WB 007 C WB 007 CG	Chrome/Gold	194
WB 008 - CORNER BASKET - MEDIUM WB 009 - CORNER BASKET - SMALL	WB 008 C WB 008 CG	Chrome Chrome/Gold	164 85.5
WB 010 - CURNER BASKET - SMALL WB 010 - SEMI-CIRCULAR BASKET - LARG	WB 009 C WB 009 CG	Chrome Chrome/Gold	147 65.5
2 Con Sory Grab Pail Manual	WB 010 C WB 010 CG	Chrome Chrome/Gold	164



BATHROOM RAILS - COMFORT COLLECTION

All purpose 25 mm rail for kitchen and bathroom support use. Not specifically designed for people with disabilities. Fabricated from 304 stainless steel with 50 mm triple screw wall mount plates and screw on end caps.

Coloured rails are only made to order and are non-returnable.

	Code	Finish	Features
300 mm - 25 mm COMFORT RAIL	CR 300 PS CR 300 FC CR 300 ACG CR 300 G	Polish Supreme [™] Full Colour Colour/Gold Gold	300 mm Ø to Ø wall fixings. Stainless steel 304.
450 mm - 25 mm COMFORT RAIL 600 mm - 25 mm COMFORT RAIL	CR 450 PS CR 450 FC CR 450 ACG CR 450 G	Polish Supreme [™] Full Colour Colour/Gold Gold	450 mm Ø to Ø wall fixings. Stainless steel 304.
	CR 600 PS CR 600 FC CR 600 ACG CR 600 G	Polish Supreme [™] Full Colour Colour/Gold Gold	600 mm Ø to Ø wall fixings. Stainless steel 304. [80] [600]
900 mm - 25 mm COMFORT RAIL	CR 900 PS CR 900 FC CR 900 ACG CR 900 G	Polish Supreme™ Full Colour Colour/Gold Gold	900 mm Ø to Ø wall fixings. Stainless steel 304.
1200 mm - 25 mm COMFORT RAIL	CR 1200 PS CR 1200 FC CR 1200 ACG CR 1200 G	Polish Supreme [™] Full Colour Colour/Gold Gold	1200 mm Ø to Ø wall fixings. Stainless steel 304.
210 mm x 210 mm - 25 mm RAMPED COI	CR 036 C	BASKET Chrome	385 mm Ø to Ø wall fixings with 133 mm rise. Suitable for either left or right hand installation. Chrome plated brass.
600 mm - 25 mm BATH TOWEL SHELF	CR 022 C	Chrome	600 mm Ø to Ø wall fixings. Chrome plated brass.



Shower Systems for Healthcare Applications

Shower systems for healthcare applications usually require the installation of height adjustable handheld showers to cater for the able bodied as well as those who need to use a shower chair to clean themselves. There must also be provisions for assistance where someone is incapable of performing the cleaning task unaided. Handheld showers for these applications should be light weight, capable of withstanding dropping, easily held in soapy hands and have a soft spray pattern as to not irritate sensitive skin. Hoses should have a smooth surface to allow thorough cleaning as well. Con-Serv's Hosfab® handheld showers and hoses meet these requirements.

Where requested a handpiece that has an additional pulsating action to relax or to provide aqua-massage hydrotherapy treatment to relieve pain or promote healing can be supplied.

Handheld showers for professional use are supplied with licenced dual check valves to stop contamination of the water system. As with all Con-Serv handheld showers, the valves are located with the flow control at the wall outlet elbow.

Careful selection from the HOSFAB® range will result in a shower support system that has been designed to fit many applications and give years of reliable service.



Select from our four ranges of HOSFAB® shower systems for healthcare applications

PWD HOSFAB®	. 12 - 13
Commercial HOSFAB®	. 14 - 17
Standard HOSFAB®	. 18 - 21
Premium HOSFAB®	. 22 - 25













REFERENCE GUIDE TO COMMERCIAL HS 018 & PWD HOSFAB® KITS







PWD HOSFAB® - INDEPENDENT ACCESSIBLE HEALTHCARE SHOWER KIT FOR SEATED USERS

1000 mm Satin Supreme 304 independent accessible grab rail/shower kit, assembled with 50 mm HYGIENIC SEAL® healthsafe flange covers and Brass Friction Slide Cradle with "PUSH-PULLME®" handset height adjustment rod for seated users. The HYGIENIC SEAL® healthsafe flange with Thermoplastic Elastomer (TPE) fitted seal prevents grime such as soap scum, body fluids, ointments and aqueous based fluids accumulating behind the flange cover and creating possible serious health issues. Putting health and hygiene foremost, the grab rails comply with clause 17 of AS 1428.1-2009 for







PWD HOSFAB® - HEALTHCARE KIT WITH PUSH-PULLME® FOR SEATED USERS

Independent accessible healthcare kits are made from the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. The grab rails are fabricated from 304 stainless steel and assembled with 50 mm chromed brass screw on HYGIENIC SEAL® flange covers with Thermoplastic Elastomer (TPE) fitted seals and comply with clause 17 of AS 1428.1-2009 for Design and Construction.



AS 1428.1 - 2009 15.5.6 Shower Head

An adjustable shower head holder shall be provided to support the shower head and shall allow the graspable portion of the shower head to be positioned at various angles and heights and also allow the graspable portion of the shower head to be located at heights between 1000 mm and 1800 mm above the plane of the finished floor and allow access and adjustment from a seated position.

The above clause only applies to bathrooms specifically designed for People with Disabilities (PWD) in public buildings, factories, hotels, motels and designated PWD bathrooms in hospitals, homes for the elderly and nursing homes.

Finish

1000 Brass Friction Slide Cradle with Push-PullMe®

PWD						
	ID 018-03 CW	Chrome/White 1.5 m hose				
	ID 018-03 C	Chrome 1.5 m hose				
	ID 018-03 CW2	Chrome/White 2 m hose				
	ID 018-03 C2	Chrome 2 m hose				

Code

Features


1000 mm Satin Supreme™ grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers and **Brass Friction Slide Cradle** with PUSH-PULLME® shower height adjustment rod for seated persons. Also includes a strong and stylish ABS handpiece, PVC reinforced Softflex® spiral hose and wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/ non return valves to prevent back siphonage.

3 Star - 9 L/min rated as per WELS licence number 0046. Complies with requirements for a 2 walled shower enclosure when installed with HS 700 as per 1428.1-2009.





INDICATIVE IMAGE ONLY (Refer to page 54, figure 48 for recommended positioning)



ID 018-20 CW	Chrome/White 1.5 m hose
ID 018-20 C	Chrome 1.5 m hose
ID 018-20 CW2	Chrome/White 2 m hose
ID 018-20 C2	Chrome 2 m hose

Please specify left or right hand



TO SUIT ACCESSIBLE SHOWER RECESS.

700 mm x 1100 mm Satin Supreme™ inverted "T" handed grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers and **Brass Friction Slide Cradle** with PUSH-PULLME shower height adjustment rod for seated persons. Also includes a strong and stylish ABS handpiece, PVC reinforced Soffflex® spiral hose and wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non return valves to prevent back siphonage.

3 Star - 9 L/min rated as per WELS licence number 0046. Complies with requirements for a 2 walled shower enclosure as per 1428.1-2009





INDICATIVE IMAGE ONLY (Refer to page 54, figure 48 for recommended positioning)

ID 018-21 INDEPENDENT HOSFAB® - PWD Please specify left or right hand ID 018-21 CW Chrome/White 1.5 m hose ID 018-21 C Chrome 1.5 m hose ID 018-21 CW2 Chrome/White 2 m hose ID 018-21 C2 Chrome 2 m hose ID 018-21 C2 Chrome 2 m hose

TO SUIT COMBINED ACCESSIBLE SANITARY COMPARTMENT.

1170 mm x 1100 mm Satin Supreme™ inverted "T"handed grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers and **Brass Friction Slide Cradle** with PUSH-PULLME shower height adjustment rod for seated persons. Also includes a strong and stylish ABS handpiece, PVC reinforced Soffflex® spiral hose and wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non return valves to prevent back siphonage.

 $3\ Star$ - $9\ L/min$ rated as per WELS licence number 0046. Complies with requirements for a 2 walled shower enclosure as per 1428.1-2009.





INDICATIVE IMAGE ONLY (Refer to page 56, figure 50 for recommended positioning)



COMMERCIAL HOSFAB® - HEALTHCARE SHOWER KIT WITH BRASS FRICTION SLIDE CRADLE AND ABS SLIDE CRADLE OPTIONS

900 mm Satin Supreme 304 grab rail/shower kit, assembled with 50 mm HYGIENIC SEAL® healthsafe flange covers and BRASS FRICTION SLIDE CRADLE (ABS OPTIONAL). The HYGIENIC SEAL® healthsafe flange with Thermoplastic Elastomer

(TPE) fitted seal prevents grime such as soap scum, body fluids, ointments and aqueous based fluids accumulating behind the flange cover and creating possible serious health issues. Putting health and hygiene foremost, the grab rails comply with clause 17 of AS 1428.1-2009 for Design and Construction.







COMMERCIAL HOSFAB® - OPTIONS

Commercial healthcare shower support options, made from the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Designed for installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Grab rail kits comply with clause 17 of 1428.1-2009 for

Design and Construction.

WaterMark
ASINZS 3662

		Code	Finish	Features	WaterMark AS/NZS 3662 WMKT 21147	5
	HS 018 KIT 1					
		HS 018-01 CW	Chrome/White 1.5 m hose and handpiece	Handheld shower kit with stylish ABS reinforced Softflex® spiral hose and w which features 9 L/min Flow Intercha licenced dual check/non-return valve	vall outlet elbow bra nge Spigot and sep	acket oarate
		HS 018-01 C	Chrome 1.5 m hose and handpiece	3 Star - 9 L/m rated as per WELS lice	ence number 0046.	
	E E					
	HS 018 KIT 3					
		HS 018-03 CW	Chrome/White 1.5 m hose and handpiece	900 mm Satin Supreme™ grade 304 g HYGIENIC SEAL® healthsafe flange cov Slide Cradle fastened and tensioned to support and movement. Also includes	vers with Brass Fric to the grab rail for ha a strong and stylish	ction landset ABS
		HS 018-03 C	Chrome 1.5 m hose and handpiece	handpiece, PVC 1.5 m reinforced Softi outlet elbow which features 9 L/min FI separate licenced dual check/non retu siphonage.	low Interchange Spig Irn valves to prevent	got and t back
	Brass Friction Slide Cradle	HS 018-03 CW2	Chrome/White 2 m hose and handpiece	3 Star - 9 L/min rated as per WELS lic Complies with requirements for 2 wall installed with HS 700 as per AS 1428	ed shower enclosure	
	J	HS 018-03 C2	Chrome 2 m hose and handpiece	AS 1428.1		
				HYGIENIC SEAL® DIMENSIONAL COMPLIANT		
	HS 018 KIT 5	Please specify left (or right hand			
	,	HS 018-05 CW	Chrome/White 1.5 m hose	760 mm x 1000 mm x 1100 mm Sati	n Supreme™ grade	304
			and handpiece	grab rail, assembled with HYGIENIC SE covers with Brass Friction Slide Crac to the grab rail for handset support an	lle fastened and ten d movement. Also ir	nsioned ncludes
		HS 018-05 C	Chrome 1.5 m hose and handpiece	a strong and stylish ABS handpiece, P' Softflex® spiral hose and wall outlet el Flow Interchange Spigot and separate	bow which features licenced dual check	9 L/min
	Brass Drawn right hand Friction Slide Cradle	HS 018-05 CW2	Chrome/White 2 m hose and handpiece	return valves to prevent back siphonag 3 Star - 9 L/min rated as per WELS lice		i.
		HS 018-05 C2	Chrome 2 m hose and handpiece			
	Drawn left hand			(HYGIENIC SEAL®		
	HS 018 KIT 6					
		HS 018-06 CW	Chrome/White 1.5 m hose and handpiece	Handheld shower kit to suit 32 mm grincludes ABS Glide Slide Cradle to but the grab rail for handset support and r	e fastened and tensi	ioned to
		HS 018-06 C	Chrome 1.5 m hose and handpiece	stylish ABS handpiece, PVC 1.5 m rein and wall outlet elbow which features 9	nforced Softflex® spi L/min Flow Interch	iral hose lange
	ABS Glide Slide	HS 018-06 CW2	Chrome/White 2 m hose	Spigot and separate licenced dual che back siphonage.		event
	Cradle	HS 018-06 C2	and handpiece Chrome 2 m hose	3 Star - 9 L/m rated as per WELS licence number NO GRAB RAIL SUPPLIED		
	1 1		and handpiece			
	HS 018 KIT 7	110.040.07.6	Olympia AAII II a 4 5	Development of the state of the	1 00 mars "	
		HS 018-07 CW	Chrome/White 1.5 m hose and handpiece	Psychiatric care handshower kit to sui refurbishment with quick release cou	•	k
	(HS 018-07 C	Chrome 1.5 m hose	stop valve. Kit also includes the HOSFA pressure reinforced Black Silver Braid		
	¥ €		and handpiece	outlet elbow which features 9L/min Flo	ow Interchange Spig	got
		HS 018-07 CW2	Chrome/White 2 m hose	and separate licenced dual check/non siphonage.	return to prevent ba	ack
			and handpiece	3 Star - 9 L/m rated as per WELS licer	nce number 0046.	
	9	HS 018-07 C2	Chrome 2 m hose and handpiece	NO GRAB RAIL SUPPLIED		
			and nanodiece			

and handpiece



COMMERCIAL HOSFAB® - OPTIONS

Commercial healthcare shower support options, made from the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Designed for installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Grab rail kits comply with clause 17 of 1428.1-2009 for Design and Construction.

WaterMark Code Finish Features **HS 018 KIT 9** Chrome/White 1.5 m hose 900 mm Satin Supreme™ grade 304 grab rail, assembled HS 018-09 CW HYGIENIC SEAL® healthsafe flange covers with ABS Glide and handpiece Slide Cradle fastened and tensioned to the grab rail for handset support and movement. Also includes a strong and stylish ABS handpiece, PVC reinforced Softflex® spiral HS 018-09 C Chrome 1.5 m hose hose and wall outlet elbow which features 9 L/min Flow Interchange spigot and separate licenced dual check/non and handpiece return valves to prevent back siphonage. ABS Glide 3 Star - 9 L/min rated as per WELS licence number 0046. Slide Cradle HS 018-09 CW2 Chrome/White 2 m hose Complies with requirements fo a 2 walled shower enclosure and handpiece when installed with HS 700 SS as per AS 1428.1 -2009. HS 018-09 C2 Chrome 2 m hose and handpiece HYGIENIC SEAL **HS 018 KIT 12** HS 018-12 CW Chrome/White 1.5 m hose Handheld shower kit to suit 32 mm grab rail refurbishment. Also includes a stylish ABS handpiece, PVC 1.5 m reinforced and handniece Softflex® spiral hose and wall outlet elbow which features 9 L/ HS 018-12 C Chrome 1.5 m hose min Flow Interchange Spigot and separate licenced dual check/ non-return valve to prevent back siphonage. and handpiece 3 Star - 9 L/m rated as per WELS licence number 0046. HANDHELD SHOWER KIT FOR ALL GRAB RAIL MODELS. HS 018-12 CW2 Chrome/White 2 m hose and handpiece HS 018-12 C2 Chrome 2 m hose and handpiece **HS 018 KIT 13** Please specify left or right hand Chrome/White 1.5 m hose 760 mm x 1000 mm x 1100 mm Satin Supreme™ grade 304 HS 018-13 CW grab rail assembled with HYGIENIC SEAL® healthsafe flange and handpiece covers with ABS Glide Slide Cradle fastened and tensioned to the grab rail for handset support and movement. Also includes a strong and stylish ABS handpiece, PVC reinforced Softflex® HS 018-13 C Chrome 1.5 m hose spiral hose and wall outlet elbow which features 9 L/min Flow and handpiece Interchange Spigot and separate licenced dual check/non return valves to prevent back siphonage. ABS Glide Slide 3 Star - 9 L/min rated as per WELS licence number 0046. Chrome/White 2 m hose HS 018-13 CW2 and handpiece Drawn right hand HS 018-13 C2 Chrome 2 m hose and handpiece HYGIENIC SEAL® Drawn left hand **HS 018 KIT 14** Please specify left or right hand 400 mm x 1100 mm Satin Supreme™ grade 304 "L" shape grab rail assembled with HYGIENIC SEAL® healthsafe flange covers HS 018-14 CW Chrome/White 1.5 m hose and handpiece with ABS Glide Slide Cradle fastened and tensioned to the grab rail for handset support and movement. Also includes a strong and stylish ABS handpiece, PVC reinforced Softflex® spiral hose and wall outlet elbow which features 9 L/min Flow Interchange ABS Glide Slide Cradle HS 018-14 C Chrome 1.5 m hose Spigot and separate licenced dual check/non return valves to and handpiece prevent back siphonage 3 Star - 9 L/min rated as per WELS licence number 0046. HS 018-14 CW2 Chrome/White 2 m hose MADE TO ORDER - NON RETURNABLE and handpiece

HS 018-14 C2

Drawn right hand

Chrome 2 m hose and handpiece

HYGIENIC SEAL®



COMMERCIAL HOSFAB® - OPTIONS

Commercial healthcare shower support options, made from the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Designed for installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Only left and right handed kits comply with dimensional requirements of AS 1428.1-2009 but all comply with clause 17 of 1428.1-2009 for Design and Construction.

WaterMark Code Finish Features **HS 018 KIT 16** Please specify left or right or centre fix 700 mm x 1100 mm Satin Supreme™ grade 304 inverted "T"grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers and HS 018-16 CW Chrome/White 1.5 m hose and handpiece ABS GLIDE SLIDE CRADLE fastened and tensioned to the grab rail for handset support and movement. Also includes a strong and stylish handpiece, PVC reinforced Softflex® spiral hose and wall HS 018-16 C Chrome 1.5 m hose ARS Glide outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non return valves to prevent back and handpiece siphonage Drawn 3 Star - 9 L/min rated as per WELS licence number 0046. right hand HS 018-16 CW2 Chrome/White 2 m hose Complies with requirements for a 2 walled shower enclosure as per AS 1428.1-2009. and handpiece Left and right hand models only comply to AS 1428.1 Drawn centre fix HS 018-16 C2 Chrome 2 m hose and handpiece HYGIENIC SEAL® Drawn left hand **HS 018 KIT 20** Please specify left or right or centre fix 700 mm x 1100 mm Satin Supreme™ grade 304 inverted "T' grab rail, assembled with HYGIENIC SEAL® healthsafe flange HS 018-20 CW Chrome/White 1.5 m hose and handpiece covers and BRASS FRICTION SLIDE CRADLE fastened and tensioned to the grab rail for handset support and movement. Also includes a strong and stylish handpiece, PVC reinforced HS 018-20 C Chrome 1.5 m hose Softflex® spiral hose and wall outlet elbow which features 9 L/ min Flow Interchange Spigot and separate licenced dual check/ and handpiece non return valves to prevent back siphonage Friction 3 Star - 9 L/min rated as per WELS licence number 0046. Drawn Slide HS 018-20 CW2 Chrome/White 2 m hose right hand Left and right hand models only comply to AS 1428.1 and handpiece HS 018-20 C2 Drawn centre fix Chrome 2 m hose and handpiece HYGIENIC SEAL® Drawn left hand HS 018 KIT 21 Please specify left or right hand 1170 mm x 1100 mm Satin Supreme $^{\text{TM}}$ grade 304 inverted "T"grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers and BRASS FRICTION SLIDE CRADLE fastened and tensioned to the grab HS 018-21 CW Chrome/White 1.5 m hose and handpiece rail for handset support and movement. Also includes a strong and stylish handpiece. PVC reinforced Softflex® spiral hose and wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non return valves to prevent back siphonage. HS 018-21 C Chrome 1.5 m hose and handpiece 3 Star - 9 L/min rated as per WELS licence number 0046. Complies Brass with requirements for a 2 walled shower enclosure as per AS 1428.1-Friction Slide Cradle HS 018-21 CW2 Chrome/White 2 m hose Drawn right hand 2009 and handpiece HS 018-21 C2 Chrome 2 m hose and handpiece HYGIENIC SEAL® Drawn left hand **HS 018 KIT 22** A.B.C. WASH DOWN KIT HS 018-22 CB Chrome/Black Silver braid A - Automobiles, B - Boats, C - Childcare Centres. The Colt trigger wash down gun with on/off lock function adjusts to variable spray 900 mm hose patterns. Supplied with PVC heavy duty reinforced smooth hose,

HS 018-22 CB1

HS 018-22 CB2

HS 018-22 CB3

Chrome/Black Silver braid

Chrome/Black Silver braid

Chrome/Black Silver braid

1.5 mm mm hose

2 mm mm hose

3 m hose

right angled wall mount gun nozzle cradle and wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate

licenced dual check/non-return valve to prevent back siphonage.

PLEASE NOTE: The colt has a maximum

NOT TO BE USED AS LINE END

STOP CONTROL

operating pressure of 550 kPa (80PSI) with maximum operating temperature of 55°C.



STANDARD HOSFAB® - HEALTHCARE SHOWER KIT WITH ABS GLIDE SLIDE CRADLE

900 mm Polished Supreme 304 grab rail/shower kit, assembled with 50 mm HYGIENIC SEAL® healthsafe flange covers and ABS GLIDE SLIDE CRADLE fastened and tensioned to the grab rail for handset support and movement. The HYGIENIC SEAL® healthsafe flange covers with Thermoplastic Elastomer (TPE) fitted seal prevent grime such as soap scum, body fluids, ointments and aqueous based fluids accumulating behind the grab rail flange and creating possible serious health issues. Putting health and hygiene foremost, the grab rails comply with clause

17 of AS 1428.1-2009 for Design and Construction.





STANDARD HOSFAB® - SELECTIONS 900 mm WITH ABS GLIDE SLIDE CRADLE

Home and healthcare shower selections with 900 mm Polished Supreme grade 304 grab rail, assembled with the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Suits installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Selections comply with clause 17 of AS 1428.1-2009 for Design and Construction.

	Codo	Finish	Footures	WaterMark AS/NZS 3662	E
GS 900 C CHAMPAGNE PULSATOR	Code	Finish	Features	WMKT 21147	
	GS 900 C-C GS 900 C-WTC GS 900 C-WTG GS 900 C-SC GS 900 C-CG GS 900 C-G	Polish Supreme™ White/Chrome White/Gold Satin Completely Chrome/Gold Gold	900 mm Polished Supreme™ grade 304 grab HYGIENIC SEAL® healthsafe flange covers with fastened and tensioned to the grab rail for han movement. Kit includes ABS Champagne Pulsa m reinforced Softflex® spiral hose and wall out 9 L/min Flow Interchange Spigot and separate return valves to prevent back siphonage. 3 Star - 9 L/m rated as per WELS licence num Complies with requirements for a 2 walled sho installed with HS 700 PS as per AS 1428.1-20	ABS Glide Slide Cr. dset support and tor handpiece, PVC let elbow which fea licenced dual check ber 0046.	adle 1.5 tures v/non-
GS 900 P PRINCESS	GS 900 P-C GS 900 P-ACC GS 900 P-ACG GS 900 P-CG GS 900 P-G	Polish Supreme™ Colour/Chrome Colour/Gold Chrome/Gold Gold	900 mm Polished Supreme™ grade 304 grab HYGIENIC SEAL® healthsafe flange covers with Cradle fastened and tensioned to the grab rail movement. Kit includes ABS Princess handpied Softflex® spiral hose and wall outlet elbow whi Interchange Spigot and separate licenced dual to prevent back siphonage. 3 Star - 9 L/m rated as per WELS licence num Complies with requirements for a 2 walled sho installed with HS 700 PS as per AS 1428.1-20	ABS Glide Slide for handset suppor ce, PVC 1.5 m reinfo ch features 9 L/min check/non-return v ber 0046.	t and orced Flow alves
GS 900 F HOSFAB	GS 900 F-C GS 900 F-WTC	Polish Supreme™ White/Chrome	900 mm Polished Supreme™ grade 304 grab HYGIENIC SEAL® healthsafe flange covers with Cradle fastened and tensioned to the grab rail movement. Kit includes ABS Hosfab handpiece Softflex® spiral hose and wall outlet elbow whi Interchange Spigot and separate licenced dual to prevent back siphonage. 3 Star - 9 L/m rated as per WELS licence num Complies with requirements for a 2 walled sho installed with HS 700 PS as per AS 1428.1-20 IMENSIONAL COMPLIANT	ABS Glide Slide for handset suppor , PVC 1.5 m reinfor ch features 9 L/min check/non-return v ber 0046. wer enclosure when	t and ced Flow alves



STANDARD HOSFAB® - SELECTIONS 700 mm x 1100 mm WITH ABS GLIDE SLIDE CRADLE

Home and healthcare shower selections with 700 mm x 1100 mm Polished Supreme grade 304 inverted "T" grab rail, assembled with the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Suits installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Only left and right

handed kits comply with dimensional requirements of AS 1428.1-2009 but all comply with clause 17 of 1428.1-2009 for Design and Construction.



		Code	Finish	Features
GS 071 C CHAMPAGNE PULSATOR	Please	specify left or rig	nt or centre fix	
		GS 071 C-C	Polish Supreme™	700 mm x
A B	a	GS 071 C-WTC	White/Chrome	rail, assem
1 1	1	GS 071 C-WTG	White/Gold	covers and to the grab
P	P	GS 071 C-CG	Chrome/Gold	includes AE
4 9	*			reinforced s features 9
	11 1			licenced du
1 1 1				siphonage.
I\ <i>)</i>	V			3 Star - 9 L
ا ۱۱ هـ ۱				
				Left and ri
Drawn left hand	Drawn right hand			
(a)	3			
@				
Drawn centre fix				
				HYGIENIC S
GS 071 P PRINCESS	Please	specify left or rig		
		CC 071 D C	Daliah CupramaTM	700 mm v

x 1100 mm Polished Supreme™ inverted "T" grab nbled with HYGIENIC SEAL® healthsafe flange d ABS Glide Slide Cradle fastened and tensioned b rail for handset support and movement. Kit ABS Champagne Pulsator handpiece, PVC 1.5 m Softflex® spiral hose and wall outlet elbow which L/min Flow Interchange Spigot and separate dual check/non return valves to prevent back

L/min rated as per WELS licence number 0046.

right hand models only comply to AS 1428.1





Drawn left hand Drawn right hand

Drawn centre fix

GS 071	P-C	Polish Supreme™
GS 071	P-ACC	Colour/Chrome
GS 071	P-ACG	Colour/Gold
CC 071	D CC	Chromo/Gold

700 mm x 1100 mm Polished Supreme™ inverted "T"grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers and ABS Glide Slide Cradle fastened and tensioned to the grab rail for handset support and movement. Kit includes ABS Princess handpiece, PVC 1.5 m reinforced Softflex® spiral hose and wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non return valves to prevent back siphonage.

3 Star - 9 L/min rated as per WELS licence number 0046

Left and right hand models only comply to AS 1428.1





GS 071 F HOSFAB		Please	specify left or righ	t or centre fix
			GS 071 F-C	Polish Suprem
		(A	GS 071 F-WTC	White/Chrome
1	7	1		
P		P		
4		** **		
	(m) (n)			
		 		
1\1		V		
Drawn left hand	\mathbf{V}	Drawn right hand		
Brann for mana		21am ngu nana		
0				
	Drawn centre fix			

GS 071 F-C	Polish Supreme™
GS 071 F-WTC	White/Chrome

700 mm x 1100 mm Polished Supreme™ inverted "T"grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers and ABS Glide Slide Cradle fastened and tensioned to the grab rail for handset support and movement. Kit includes ABS Hosfab® handpiece, PVC 1.5 m reinforced Softflex® spiral hose and wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non return valves to prevent back siphonage.

3 Star - 9 L/min rated as per WELS licence number

Left and right hand models only comply to AS 1428.1








Drawn left hand

STANDARD HOSFAB® - SELECTIONS 1170 mm x 1100 mm WITH ABS GLIDE SLIDE CRADLE

Home and healthcare shower selections with 1170 mm x 1100 mm Polished Supreme grade 304 inverted "T" grab rail, assembled with the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Suits installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Complies with dimensional requirements of 1428.1-2009

and Clause 17 of 1428.1-2009 for Design and Construction.



HYGIENIC SEAL®



PREMIUM HOSFAB® - HEALTHCARE SHOWER KIT WITH SLIDE TRACK & HANDSET CRADLE

900 mm Polished Supreme 304 grab rail/shower kit, assembled with 50 mm HYGIENIC SEAL® healthsafe flange covers and 685 mm FRICTION SLIDE TRACK CRADLE secured to the grab rail for handset support and movement and most suitable for persons with weakened wrists, arthritic and grip problems. The HYGIENIC SEAL® healthsafe flange covers with Thermoplastic Elastomer (TPE) fitted seal prevent grime such as soap scum, body fluids, ointments and aqueous based fluids accumulating behind the flange cover and creating possible serious health issues. Putting health and hygiene foremost, the grab rails comply with clause 17 of AS 1428.1-2009 for Design and Construction.





PREMIUM HOSFAB® - SELECTIONS 900 mm WITH FRICTION SLIDE TRACK & CRADLE

Home and healthcare shower selections with 900 mm Polished Supreme grade 304 grab rail, assembled with the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Suits installations in hospitals, homes for the elderly and nursing homes. Selections comply with clause 17 of AS 1428.1-2009 for Design and Construction.



	Code	Finish	Features WaterMark ASINZS 3662 WMKT 21147
GB 900 C - CHAMPAGNE PULSATOR	GB 900 C-C GB 900 C-WTC GB 900 C-WTG GB 900 C-SC GB 900 C-CG GB 900 C-G	Polish Supreme™ White/Chrome White/Gold Satin Completely Chrome/Gold Gold	900 mm Polished Supreme™ 304 grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers with 685 mm Friction Slide Track and Cradle secured to the grab rail for handset support and movement. Kit includes ABS Champagne pulsator handpiece,PVC 1.5 m Silverflex® or appropriate coloured spiral hose, a grab rail soap dish to suit, wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non-return valve to prevent back siphonage. 3 Star - 9 L/m rated as per WELS licence number 0046.
			HYGIENIC SEAL®
GB 900 P - PRINCESS	GB 900 P-C GB 900 P-ACC GB 900 P-ACG GB 900 P-CG GB 900 P-G	Polish Supreme™ Colour/Chrome Colour/Gold Chrome/Gold Gold	900 mm Polished Supreme [™] 304 grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers with 685 mm Friction Slide Track and Cradle secured to the grab rail for handset support and movement. Kit includes ABS Princess handpiece, PVC 1.5 m Silverflex® or appropriate coloured spiral hose, a grab rail soap dish to suit, wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non-return valve to prevent back siphonage. 3 Star - 9 L/m rated as per WELS licence number 0046.
			HYGIENIC SEAL®
GB 900 F - HOSFAB®	GB 900 F-C GB 900 F-WTC	Polish Supreme [™] White/Chrome	900 mm Polished Supreme™ 304 grab rail, assembled with HYGIENIC SEAL® healthsafe flange covers with 685 mm Friction Slide Track and Cradle secured to the grab rail for handset support and movement. Kit includes ABS Hosfab® handpiece, PVC 1.5 m Silverflex® or appropriate coloured spiral hose, a grab rail soap dish to suit, wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non-return valve to prevent back siphonage. 3 Star - 9 L/m rated as per WELS licence number 0046.

(HYGIENIC SEAL®)



PREMIUM HOSFAB® - SELECTIONS 700 mm x 1100 mm WITH FRICTION SLIDE TRACK & CRADLE

Home and healthcare shower selections with 700 mm x 1100 mm inverted "T" Polished Supreme™ grade 304 grab rail, assembled with the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Suits installations in hospitals, homes for the elderly and nursing homes. Selections comply with clause 17 of AS 1428.1-2009 for Design and Construction.



Code Finish Features GB 071 C - CHAMPAGNE PULSATOR Please specify left or right or centre fix GB 071 C-C Polish Supreme™ 700 mm x 1100 mm Polished Supreme™ inverted "T" grab rail, assembled with HYGIENIC SEAL® healthsafe flange GB 071 C-WTC White/Chrome covers and 685 mm Friction Slide Track and Cradle GB 071 C-WTG White/Gold secured to the grab rail for handset support and movement. Kit includes ABS Champagne Pulsator handpiece, PVC 1.5 GB 071 C-CG Chrome/Gold m smooth Silverflex® or appropriate coloured spiral hose, a grabrail soap dish, wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/ non return valves to prevent back siphonage. 3 Star - 9 L/min rated as per WELS licence number 0046. Drawn left hand Drawn right hand Drawn centre fix HYGIENIC SEAL GB 071 P - PRINCESS Please specify left or right or centre fix GB 071 P-C Polish Supreme™ 700 mm x 1100 mm Polished Supreme™ inverted "T" grab rail, assembled with HYGIENIC SEAL® healthsafe flange Colour/Chrome GB 071 P-ACC covers and 685 mm Friction Slide Track and Cradle GB 071 P-ACG Colour/Gold secured to the grab rail for handset support and movement. GB 071 P-CG Kit includes ABS Princess handpiece, PVC 1.5 m smooth Chrome/Gold Silverflex® or appropriate coloured spiral hose, a grabrail soap dish, wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non return valves to prevent back siphonage. 3 Star - 9 L/min rated as per WELS licence number 0046. Drawn left hand Drawn right hand Drawn centre fix HYGIENIC SEAL®

ab of the mooths	1 100
Drawn left hand Drawn centre fix	Drawn right hand

Please specify left or right or centre fix GB 071 F-C Polish Supreme™ White/Chrome **GB 071 F-WTC**

700 mm x 1100 mm Polished Supreme™ inverted "T" grab rail, assembled with HYGIENIC SEAL® healthsafe flangecovers and 685 mm Friction Slide Track and Cradle secured to the grab rail for handset support and movement. Kit includes ABS Hosfab® handpiece, PVC 1.5 m smooth Silverflex® or appropriate coloured spiral hose, a grabrail soap dish, wall outlet elbow which features 9 L/min Flow Interchange Spigot and separate licenced dual check/non return valves to prevent back siphonage.

3 Star - 9 L/min rated as per WELS licence number 0046.




GR 071 F - HOSFAR®



PREMIUM HOSFAB® - SELECTIONS 760 mm x 1000 mm x 1100 mm WITH FRICTION SLIDE TRACK & CRADLE

Home and healthcare shower selections with 760 mm x 1000 mm x 1100 mm Polished Supreme grade 304 grab rail, assembled with the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Suits installations in hospitals, homes for the elderly and nursing homes. Selections comply with clause 17 of AS 1428.1-2009 for Design and Construction.





Drawn right hand

Drawn left hand

3 Star - 9 L/min rated as per WELS licence number 0046.


HYGIENIC SEAL®

HEALTHCARE KIT ACCESSORIES



Con-Serv 32 mm grab rail exclusive products.

			L
	Code	Finish	Features
SB 024 - GRAB RAIL GLIDE SLIDE HANDSET	CRADLE		
	HC 024 BLC	Black/Chrome	Fastens to 32 mm grab rail
	HC 024 GYC	Grey/Chrome	Clicklock TM claw mechanism ABS construction
	HC 024 WT	White	Simple to clean
	HC 024 SC	Satin/Chrome	
	HC 024 ACG	Colour/Gold	
TR 031 - GRAB RAIL FLEXIBLE FIX AND STAIL	NLESS STEEL TOILET R	OLL HOLDER	
	TR 031 BLC	Black/Chrome	Fastens to 32 mm grab rail
	TR 031 GYC	Grey/Chrome	ABS construction Simple to clean
	TR 031 WT	White	Fits all 32 mm toilet assist grab rails
	TR 031 SC	Satin/Chrome	
ABS Stainless Steel	TR 031 ACG	Colour/Gold	
	TR 031 SS	Stainless Steel	Stainless steel toilet roll holder
			FACTORY FITTED
SD 032 - GRAB RAIL SOAP DISH HOLDER			
	SD 032 BLC	Black/Chrome	Fastens to 32 mm grab rail
	SD 032 GYC	Grey/Chrome	ABS construction
	SD 032 WT	White	Simple to clean
	SD 032 W1	Satin/Chrome	
	SD 032 ACG	Colour/Gold	
	3D 032 AUG	Coloul/Gold	
PM 932 - PUSH-PULLME® SHOWER POSITION	NING CRADI E WITH BO	n	
TW 332 - 1 0311-1 OLLIME SHOWER 1 0311101	PM 932 C	Chrome	Brass Friction Slide Cradle with PUSH-PULLME® shower
\top	1 IVI 332 0	Officials	height adjustment rod.
			To comply with requirements of AS 1428.1-2009 for person
			with disabilities (PWD), an adjustable shower head holder
			shall be provided to support the shower head and shall allow the graspable portion of the shower head to be positioned
350			at various angles and heights and also allow the graspable
330			portion of the shower head to be located at heights between 1000 mm and 1800 mm above the plane of the finished floor
			and allow access and adjustment from a seated position. The
			PUSH-PULLME® suits this requirement.
			FACTORY FITTED
A			
OR COS. PREMIUM COS EDIOTION OLIDE	TRACK ORABLE & COL	LADO	
SR 685 - PREMIUM 685 mm FRICTION SLIDE			Rrace construction
Τ 🜱	SR 685 C	Chrome	Brass construction Cradle adjustment for handpiece
	SR 685 ACC	Colour/Chrome	Smooth slide action
	SR 685 ACG	Colour/Gold	Self locking Recommended for those persons with arthritic or
	SR 685 SC	Satin Completely	grip problems.
	SR 685 CG	Chrome/Gold	No locking knob
685	SR 685 G	Gold	FACTORY FITTED
			MOTORI TITLE
⊥ 🐠			
HP 049 - COLT WASH DOWN GUN			
	HP 049	Chrome/Black	The colt trigger operated wash down gun with on/off lock
			function is robustly constructed and is built to last. The Colt has a maximum operating pressure of 550 Kpa (80
			PSI) and maximum operating temperature of 55°C. Nozzle
1			adjusts from narrow neck to wide pattern spray.
			NOT TO BE USED AS LINE END STOP CONTROL.
½" BSP Nipple			





	Code	Finish	Features
HS 032 BE - HYGIENIC SEAL® BLANK E	ND FLANGE		
	HS 032 BE	Chrome	Blank end tamperproof flange to cover Hygienic Seal® wall mount plate when the grab rail is removed, but will be required to be re-installed for use in a PWD requirement.
HS 032 FC - HYGIENIC SEAL® FLANGE (COVER		
HS 032 MP - HYGIENIC SEAL® WALL MO	HS 032 FC	Chrome	50 mm Hygienic Seal® flange cover. Follow installation instruction guide, page 65, if replacement is required. The Hygienic Seal® is a thermodynamic product designed to eliminate the risk of bathroom debris getting behind the flange and becoming unsanitary, thereby causing or conveying infection. The Hygienic Seal® is intended to assist in the promotion of hygiene, particularly in environments where this is a critical issue.
13 032 WF - HTGIENIG SEAL WALL MO	HS 032 MP	Brass	Hygienic Seal® wall screw mount plate. Designed to rotate
		5.400	screw holes to suit stud or nogging.
			Stainless steel fixing screws supplied.
TL 850 WM - TILTLOCK® "T" MOUNT BI	TL 850L WM	Brass/Nickle Plate	Concealed 4 fix nickle-plated brass "T" mount bracket
Right hand Left hand	TL 850R WM	Brass/Nickle Plate	secures TILTLOCK® to wall. Stainless steel fixing screws supplied.
TL 850 WC - TILTLOCK® (TPE) "T" MOU	NT COVER		
	TL 850 WC	White TPE	Thermo Plastic Elastomer (TPE) mount cover to conceal TILTLOCK® brass "T" mount bracket for when project specifications call for provision to be made for fold down rails to be installed at a further time.
TL 850 US - TILTLOCK® FLOOR MOUNT			
	TL 850 US	Satin Stainless	Stainless steel floor mount upstand for mounting TILTLOCK® in Bariatric situations and when wall mounting is not possible. Stainless steel fixing screws supplied.



CLAM FLANGE™ Grab Rails



Regular grab rail with 78 mm "CLAM FLANGE", domed cover, for the concealing of screw fixing points of the grab rail mount flange. The CLAM FLANGE™ snaps over notch lugs on the mount flange locking it firmly in place.

Con-Serv CLAM FLANGE™ grab rails are fabricated from 32 mm x 1.2 mm grade 304, 18/8 stainless steel, and pre-formed 75 mm 5 screw wall mount plate with 360 mm rear weld joint. Assembled with 78 mm domed CLAM FLANGE™ cover with 5 degree radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction and available in the following finishes: Satin Supreme™, Polish Supreme™, Diamond Shur-Grip® and colours of choice.


Grab Rail Specifications

Outside Diameter




Grab rails should not be less than 30 mm and not more than 40 mm outside diameter, or they shall have sectional shape within the limits of 30 mm and 40 mm diameter.

Wall Clearance



Unless otherwise specified, the clearance between grab rail and the adjacent wall surface or other obstruction shall not be less than 50 mm and not more than 60 mm. This clearance shall extend above the top of the grab rail by not less than 600 mm.


Mounting Height



All horizontal fixings to be underslung brackets as per standard requirements.

Con-Serv grab rail underslung bracket is 56 mm below rail.


Minimum Obstruction




Grab rails shall be fixed so that there is no obstruction to the hand along the top 270 degrees of the rail.


Installation Instructions for Grab Rail with Clam Flange™

Grab rails with clam flange must be fitted to a solid wall or other firm surface and installed by a qualified trades person.





Fixing to brickwork, blockwork or concrete use stainless steel 50 mm x 14 g self tapping screws.





Fixing to timber use stainless steel 50 mm x 14 g self tapping screws.

Custom Made Grab Rail Measurement Instructions

- 1. Measure all bends to the centre line.
- 2. When designing any grab rail all measurements are centre to centre of the rail.
- 3. Dimensions should be clearly shown between rail centres or to wall corners.
- 4. For handed grab rails nominate left or right hand e.g. Toilet assist rails are sitting on the pan, not looking at it.









Drawn left hand





HYGIENIC SEAL® Grab Rails - Independence with Style



When health and hygiene matter most, HYGIENIC SEAL® grab rails lead the healthcare industry with Con-Serv's own, innovation cove designed Thermoplastic Elastomer (TPE) fitted flange seal that firms to the rail wall and when installed prevents grime, such as soap scum, body fluids, ointments and aqueous based fluids accumulating behind the grab rail flange covers and creating possible serious health issues.


Only Con-Serv® HYGIENIC SEAL® Safe-Assist® Grab Rails give this Promise. Be most cautious of claims made by imitators.

Con-Serv® HYGIENIC SEAL® Safe-Assist® grab rail collection is fabricated from 32 mm x 1.2 mm, grade 304, 18/8 stainless steel and assembled with a 50 mm, 3 part machined brass screw on flange cover with 5 degree radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction and available in the following finishes: Satin Supreme™, Polish Supreme™, Diamond Shur-Grip® and colour of choice.


Tested by ETRS Pty Ltd for compliance to 1100 N mass in any position, without any permanent deformation, distortion or loosening of the fastenings. Test report registration number QRN00-2847.

Installation Guide






1. Install straight grab rails including the horizontal section of any grab rails as per AS 1428, 800-810 mm from floor to top of rail. Make sure wall surface is flat and free from contaminants.




4. Drill spot marks with 7 mm bit. Plug and screw wall mount plate to wall stud, using the 304 stainless steel screws supplied.



2. For STRAIGHT grab rails, position the flange protector guide lugs either vertical or horizontal. For CORNER grab rails, position the guide lugs horizontally "ONLY". Then mark at fixing guide lugs.



5. Fit grab rail into wall mount plate and tighten lock nut firmly.



3. Remove flange protector from grab rail flange, align guide lug marks from step 2 and mark wall through base holes to pinpoint screw holes.

Design Registration number - 311119.



6. Screw flange cover to wall mount plate, to secure the Thermoplastic Elastomer fitted HYGIENIC SEAL®

D. Locking pin

E. Screw mount plate



C D F

A. Flange cover

B. Thermoplastic Elastomer (the seal)

C. Locking nut

Grab rails and shower support rails are installed to provide safe support for persons who require assistance in toilets as well as bathrooms and should comply on installation when fixed, to contribute to its ability to withstand the required 1100 Newton force placed upon it. Concrete or brick walls do not present a problem. If a building is constructed with either metal frame or timber it is useful to know the dimensions of the studs and noggings and the place between the studs. Con-Serv® HYGIENIC SEAL® wall mount fitting have two screw holes and can be positioned and fastened at any angle to suit the stud or nogging. TOGGLE BOLTS FIXED INTO TILES, PLASTER BOARD OR OTHER WATERPROOF WALLS ARE NOT SATISFACTORY OR SAFE. Grab rails with HYGIENIC SEAL® flange must be fitted to a solid wall or other firm surface and installed by a qualified trades person.



REGULAR - STRAIGHT GRAB RAILS

CLAM FLANGE™ Safe-Assist® 32 mm grab rails, fabricated from 304 stainless steel with 78 mm pre-formed domed Clam concealed flange. Manufactured to comply with clause 17 of AS 1428.1-2009 for design and construction. For horizontal fixing of grab rails, mount 800 mm to 810 mm above floor level.

<u> </u>	Code	Finish	Features
300 mm	CF 300 SS CF 300 PS CF 300 KG CF 300 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	300 mm Ø to Ø Stainless steel fixing screws supplied.
400 mm	CF 400 SS CF 400 PS CF 400 KG CF 400 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	400 mm Ø to Ø Stainless steel fixing screws supplied.
450 mm	CF 450 SS CF 450 PS CF 450 KG CF 450 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	450 mm Ø to Ø Stainless steel fixing screws supplied. CLAM FLANGE™
500 mm	CF 500 SS CF 500 PS CF 500 KG CF 500 FC	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® Full Colour	500 mm Ø to Ø Stainless steel fixing screws supplied. CLAM FLANGE™
600 mm	CF 600 SS CF 600 PS CF 600 KG CF 600 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	600 mm Ø to Ø Stainless steel fixing screws supplied.
700 mm 100 30 Con-Serv Grab Rail Manual	CF 700 SS CF 700 PS CF 700 KG CF 700 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	700 mm Ø to Ø Stainless steel fixing screws supplied.



REGULAR - STRAIGHT GRAB RAILS

CLAM FLANGE™ Safe-Assist® 32 mm grab rails, fabricated from 304 stainless steel with 78 mm pre-formed domed Clam concealed flange. Manufactured to comply with clause 17 of AS 1428.1-2009 for design and construction. For horizontal fixing of grab rails, mount 800 mm to 810 mm above floor level.

750	Code	Finish	Features
750 mm	CF 750 SS CF 750 PS CF 750 KG CF 750 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	750 mm Ø to Ø Stainless steel fixing screws supplied CLAM FLANGE™
800 mm	CF 800 SS CF 800 PS CF 800 KG CF 800 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	800 mm Ø to Ø Stainless steel fixing screws supplied.
900 mm	CF 900 SS CF 900 PS CF 900 KG CF 900 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	900 mm Ø to Ø Stainless steel fixing screws supplied. CLAM FLANGE™
1000 mm	CF 1000 SS CF 1000 PS CF 1000 KG CF 1000 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	1000 mm Ø to Ø Stainless steel fixing screws supplied. CLAM FLANGE™
1100 mm	CF 1100 SS CF 1100 PS CF 1100 KG CF 1100 FC	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® Full Colour	1100 mm Ø to Ø Stainless steel fixing screws supplied. CLAM FLANGE™
1200 mm	CF 1200 SS CF 1200 PS CF 1200 KG CF 1200 FC	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Full Colour	1200 mm Ø to Ø Stainless steel fixing screws supplied. CLAM FLANGE™



Optional extras: Toilet Roll Holders TR 031 Refer page 26

REGULAR - AMBULANT & TOILET GRAB RAILS

CLAM FLANGE™ Safe-Assist® 32 mm grab rails, fabricated from 304 stainless steel with 78 mm pre-formed domed Clam concealed flange. Manufactured to comply with clause 17 of AS 1428.1-2009 for design and construction. For horizontal fixing of grab rails, mount 800 mm to 810 mm above floor level.



Tiotol page 20
450 mm x 450 mm
827 450 289
Drawn left hand
450 mm x 700 mm Grab Rail required each side of toilet

CF 045 SS	Satin Supreme™
CF 045 PS	Polish Supreme™
CF 045 KG	Diamond Shur-Grip®
CF 045 FC	Full Colour

Finish

Code

450 mm x 450 mm Stainless steel fixing screws supplied. Suitable for left or right hand installation.



Features

Drawn left hand For ambulant disabilities.

Please specify left or right hand CF 457 SS Satin Supreme™ CF 457 PS Polish Supreme™ CF 457 KG Diamond Shur-Grip® CF 457 FC Full Colour

450 mm x 700 mm Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.





700 mm x 700 mm	
	1240
	452
	Drawn left hand


Please specif	y left or right hand
CF 077 SS	Satin Supreme™
CF 077 PS	Polish Supreme™
CF 077 KG	Diamond Shur-Grip®

Full Colour

CF 077 FC

700 mm x 700 mm Stainless steel fixing screws supplied.





y lett of fight hand
Satin Supreme™
Polish Supreme™
Diamond Shur-Grip®
Full Colour

870 mm x 700 mm Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.





940 mm x 7	00 mm	
	1478	1
	695 940 245	452
4	Note: Horizontal flange connects directly	to rear wall.

Please specif	y left or right hand
CF 947 SS	Satin Supreme™
CF 947 PS	Polish Supreme™
CF 947 KG	Diamond Shur-Grip®
CF 947 FC	Full Colour

940 mm x 700 mm Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.





1110 mm x 940 mm x 700 mm

1110 mm x 010 mm x 700 mm
1478
1110 524 940 245 452
Drawn left hand Suits Backrest installation

Please specify left or right hand

CF 197 SS	Satin Supreme™
CF 197 PS	Polish Supreme™
CF 197 KG	Diamond Shur-Grip®
CF 197 FC	Full Colour

1110 mm x 940 mm x 700 mm centre to wall corner Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.










REGULAR - AMBULANT & TOILET GRAB RAILS

CLAM FLANGE™ Safe-Assist® 32 mm grab rails, fabricated from 304 stainless steel with 78 mm pre-formed domed Clam concealed flange. Manufactured to comply with clause 17 of AS 1428.1-2009 for design and construction. For horizontal fixing of grab rails, mount 800 mm to 810 mm above floor level.



	TR 031 TR 031 SS Refer page 26	Code	Finish	Features	
450 mm x 450 mm					
	450	CF 454 SS CF 454 PS CF 454 KG CF 454 FC	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip [®] Full Colour	450 mm x 450 mm Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied. AS 1428.1 CLAM FLANGE™ DIMENSIONAL COMPLIANT	
Drawn left hand	For ambulant disabilities	Disease succit	to left an elabel band	CLAW FLANGE COMPLIANT	
400 mm x 600 mm			y left or right hand		
	ho op	CF 046 SS CF 046 PS	Satin Supreme™ Polish Supreme™	400 mm x 600 mm Stainless steel fixing screws supplied.	
		CF 046 KG	Diamond Shur-Grip®		
	55	CF 046 FC	Full Colour		
Drawn left hand	400			CLAM FLANGE™	
600 mm x 600 mm		Please specif	y left or right hand		
		CF 606 SS	Satin Supreme™	600 mm x 600 mm	
	6	CF 606 PS	Polish Supreme™	Stainless steel fixing screws supplied.	
		CF 606 KG	Diamond Shur-Grip®		
	600	CF 606 FC	Full Colour		
	265				
Drawn left hand	- 000			CLAM FLANGETM	
960 mm x 600 mm		Please specif	y left or right hand		
	0-	CF 966 SS	Satin Supreme™	960 mm x 600 mm	
	ď	CF 966 PS	Polish Supreme™	Complies with requirements of	



1 10000	opoonij	Total or right hand
CF 966	SS	Satin Supreme™
CF 966	PS	Polish Supreme™
CF 966	KG	Diamond Shur-Grip®
CF 966	FC	Full Colour

AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.





1030 mm x 600 mm	
Drawn left hand	Note: Horizontal flange connects directly to rear wall.

Please	specify	left or right hand
CF 106	SS	Satin Supreme™
CF 106	PS	Polish Supreme™
CF 106	KG	Diamond Shur-Grip®
CF 106	FC	Full Colour

1030 mm x 600 mm Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.





1110 mm x 1030 mm x 600 mm	
Drawn left hand Suits Backrest in	600 nstallation

Please specify	left or right hand
CF 116 SS	Satin Supreme™
CF 116 PS	Polish Supreme™
CF 116 KG	Diamond Shur-Grip®
CF 116 FC	Full Colour

1110 mm x 1030 mm x 600 mm centre to wall corner Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.







REGULAR - CORNER GRAB RAILS

CLAM FLANGE™ Safe-Assist® 32 mm grab rails, fabricated from 304 stainless steel with 78 mm pre-formed domed Clam concealed flange. Manufactured to comply with clause 17 of AS 1428.1-2009 for design and construction. For horizontal fixing of grab rails, mount 800 mm to 810 mm above floor level.

	Code	Finish	Features
600 mm x 600 mm		left or right hand	
	CF 660 SS	Satin Supreme™	MADE TO ORDER NON-RETURNABLE
	CF 660 PS	Polish Supreme™	600 mm x 600 mm centre to wall corner
	CF 660 KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.
	CF 660 FC	Full Colour	
600			
600			
			CLAM FLANGE™
awn left hand			CLAIVI FLANCE
'00 mm x 700 mm	Please specify	left or right hand	
	CF 770 SS	Satin Supreme™	MADE TO ORDER NON-RETURNABLE
	CF 770 PS	Polish Supreme™	700 mm x 700 mm centre to wall corner
55	CF 770 KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.
	CF 770 FC	Full Colour	
100			
700			
			OLAM FLANOFTM
rawn left hand			CLAM FLANGE™
50 mm x 750 mm	Please specify	left or right hand	
	CF 757 SS	Satin Supreme™	MADE TO ORDER NON-RETURNABLE
	CF 757 PS	Polish Supreme™	750 mm x 750 mm centre to wall corner
55	CF 757 KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.
7/7	CF 757 FC	Full Colour	
130 7579			
/50			
rawn left hand			CLAM FLANGETM
00 mm x 800 mm	Please specify	left or right hand	
	CF 880 SS	Satin Supreme™	MADE TO ORDER NON-RETURNABLE
	CF 880 PS	Polish Supreme™	800 mm x 800 mm centre to wall corner
	CF 880 KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.
55	CF 880 FC	Full Colour	
629			
800			
r \ \ \ \			
			CI AM EL ANGETM
awn left hand			CLAM FLANGE™
		left or right hand	
	CF 761 SS	Satin Supreme™	760 mm x 1000 mm centre to wall corner
	CF 761 SS	Satin Supreme™	760 mm x 1000 mm centre to wall corner
	CF 761 SS CF 761 PS	Satin Supreme™ Polish Supreme™	760 mm x 1000 mm centre to wall corner
	CF 761 SS CF 761 PS CF 761 KG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip®	760 mm x 1000 mm centre to wall corner
rawn left hand 760 mm x 1000 mm	CF 761 SS CF 761 PS CF 761 KG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip®	760 mm x 1000 mm centre to wall corner
760 mm x 1000 mm	CF 761 SS CF 761 PS CF 761 KG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip®	760 mm x 1000 mm centre to wall corner
760 mm x 1000 mm	CF 761 SS CF 761 PS CF 761 KG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip®	760 mm x 1000 mm centre to wall corner
760 mm x 1000 mm	CF 761 SS CF 761 PS CF 761 KG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip®	760 mm x 1000 mm centre to wall corner




REGULAR - SHOWER RECESS GRAB RAILS

CLAM FLANGE™ Safe-Assist® 32 mm grab rails, fabricated from 304 stainless steel with 78 mm pre-formed domed Clam concealed flange. Manufactured to comply with clause 17 of AS 1428.1-2009 for design and construction. For horizontal fixing of grab rails, mount 800 mm to 810 mm above floor level.



1000

Drawn left hand



CLAM FLANGET



PREMIUM - STRAIGHT GRAB RAILS

HYGIENIC SEAL® Safe-Assist® 32 mm grab rails, fabricated from 304 stainless steel and assembled with 50 mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The HYGIENIC SEAL® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount grab rail 800 mm to 810 mm above floor level.

	Code	Finish	Features
200 mm	HS 200 SS HS 200 PS HS 200 KG HS 200 FC HS 200 GG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip [®] Full Colour Gold	200 mm Ø to Ø Stainless steel fixing screws supplied.
300 mm	HS 300 SS HS 300 PS HS 300 KG HS 300 AC HS 300 FC HS 300 AG HS 300 GG	Satin Supreme TM Polish Supreme TM Diamond Shur-Grip [®] Colour/chrome flange covers Full colour Colour/gold dress rings Gold	300 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®
400 mm	HS 400 SS HS 400 PS HS 400 KG HS 400 AC HS 400 FC HS 400 AG HS 400 GG	Satin Supreme TM Polish Supreme TM Diamond Shur-Grip® Colour/chrome flange covers Full colour Colour/gold dress rings Gold	400 mm Ø to Ø Stainless steel fixing screws supplied.
450 mm	HS 450 SS HS 450 PS HS 450 KG HS 450 AC HS 450 FC HS 450 AG HS 450 GG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® Colour/chrome flange covers Full colour Colour/gold dress rings Gold	450 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®
500 mm	HS 500 SS HS 500 PS HS 500 KG HS 500 AC HS 500 FC HS 500 AG HS 500 GG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® Colour/chrome flange covers Full colour Colour/gold dress rings Gold	500 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®
55 600	HS 600 SS HS 600 PS HS 600 KG HS 600 AC HS 600 FC HS 600 AG HS 600 GG	Satin Supreme TM Polish Supreme TM Diamond Shur-Grip® Colour/chrome flange covers Full colour Colour/gold dress rings Gold	600 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®
700 mm	HS 700 SS HS 700 PS HS 700 KG HS 700 AC HS 700 FC HS 700 AG HS 700 GG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® Colour/chrome flange covers Full colour Colour/gold dress rings Gold	700 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®



PREMIUM - STRAIGHT GRAB RAILS

HYGIENIC SEAL® Safe-Assist® 32 mm grab rails, fabricated from 304 stainless steel and assembled with 50 mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The HYGIENIC SEAL® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount grab rail 800 mm to 810 mm above floor level.

	Code	Finish	Features
750 mm	HS 750 SS HS 750 PS HS 750 KG HS 750 AC HS 750 FC HS 750 AG HS 750 GG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip [®] Colour/chrome flange covers Full colour Colour/gold dress rings Gold	750 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®
900 mm	HS 800 SS HS 800 PS HS 800 KG HS 800 AC HS 800 FC HS 800 AG HS 800 GG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip [®] Colour/chrome flange covers Full colour Colour/gold dress rings Gold	800 mm Ø to Ø Stainless steel fixing screws supplied.
900 111111	HS 900 SS HS 900 PS HS 900 KG HS 900 AC HS 900 FC HS 900 SC HS 900 AG HS 900 GG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® Colour/chrome flange covers Full colour Satin Chrome Colour/gold dress rings Gold	900 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®
1000 mm	HS 1000 SS HS 1000 PS HS 1000 KG HS 1000 AC HS 1000 FC HS 1000 AG HS 1000 GG	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Colour/chrome flange covers Full colour Colour/gold dress rings Gold	1000 mm Ø to Ø Stainless steel fixing screws supplied.
1100 mm	HS 1100 SS HS 1100 PS HS 1100 KG HS 1100 AC HS 1100 FC HS 1100 AG HS 1100 GG	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Colour/chrome flange covers Full colour Colour/gold dress rings Gold	1100 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®
1200 mm	HS 1200 SS HS 1200 PS HS 1200 KG HS 1200 AC HS 1200 FC HS 1200 AG HS 1200 GG	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip [®] Colour/chrome flange covers Full colour Colour/gold dress rings Gold	1200 mm Ø to Ø Stainless steel fixing screws supplied. HYGIENIC SEAL®






PREMIUM - AMBULANT & TOILET GRAB RAILS

MYGIENIC SEAL® Safe-Assist® 32 mm grab rails. Fabricated from 304 stainless steel and assembled with 50 mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime.

The HYGIENIC SEAL® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800 mm to 810 mm above floor level. Refer page 26 Code Finish Features 450 mm x 450 mm 450 mm x 450 mm HS 045 SS Satin Supreme™ Stainless steel fixing screws supplied. HS 045 PS Polish Supreme™ Suitable for left or right hand installation. HS 045 KG Diamond Shur-Grip® HS 045 AC Colour/chrome flange covers HS 045 FC Full colour HS 045 AG Colour/gold dress rings HYGIENIC SEAL® Drawn left hand 450 mm x 700 mm Please specify left or right hand 988 HS 457 SS Satin Supreme™ 450 mm x 700 mm Complies with requirements of HS 457 PS Polish Supreme™ AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied. HS 457 KG Diamond Shur-Grip® Colour/chrome flange covers HS 457 AC HS 457 FC Full colour HS 457 AG Colour/gold dress rings Drawn left hand




Please specify left or right hand HS 077 SS Satin Supreme™ HS 077 PS Polish Supreme™ HS 077 KG Diamond Shur-Grip® HS 077 AC Colour/chrome flange covers HS 077 FC Full colour HS 077 AG Colour/gold dress rings

700 mm x 700 mm Stainless steel fixing screws supplied.



HYGIENIC SEAL®



40°	1
I	Drawn left hand

For ambulant disabilities.

Please specify left or right hand

H2 8/1 22	Satin Supreme ^{rm}
HS 877 PS	Polish Supreme™
HS 877 KG	Diamond Shur-Grip®
HS 877 AC	Colour/chrome flange covers
HS 877 FC	Full colour
HS 877 AG	Colour/gold dress rings

870 mm x 700 mm Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.





940 mm x 700 mm	
1478	
695 940 245	452
D	rawn left hand
Note: Horizontal flange connects directly	
4440 040 700	

Please specif	y left or right hand
HS 947 SS	Satin Supreme™
HS 947 PS	Polish Supreme™
HS 947 KG	Diamond Shur-Grip®
HS 947 AC	Colour/chrome flange covers
HS 947 FC	Full colour
HS 947 AG	Colour/gold dress rings

940 mm x 700 mm Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.





110 mm x 940 mm x 700 mm

1110 IIIII x 340 IIIII x 700 IIIII
1478
177 100 40° 452 452
Drawn left han

HS 197 SS	Satin Supreme™
HS 197 PS	Polish Supreme™
HS 197 KG	Diamond Shur-Grip®
HS 197 AC	Colour/chrome flange covers
HS 197 FC	Full colour
HS 197 AG	Colour/gold dress rings

Please specify left or right hand

1110 mm x 940 mm x 700 mm centre to wall corner Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.







Drawn left hand

Suits Backrest installation



PREMIUM - AMBULANT & TOILET GRAB RAILS

HYGIENIC SEAL® Safe-Assist® 32 mm grab rails. Fabricated from 304 stainless steel and assembled with 50 mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The HYGIENIC SEAL® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800 mm to 810 mm above floor level.

TR 031 TR 031 SS				
Refer page 26	Code	Finish	Features	
450 mm x 450 mm	Please specify	left or right hand		
	HS 454 SS	Satin Supreme™	450 mm x 450 mm	
	HS 454 PS	Polish Supreme™	Complies with requirements of	
55 450	HS 454 KG	Diamond Shur-Grip®	AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.	
		·	AS 1428.1	
	HS 454 AC	Colour/chrome flange covers	A3 1420.1	
115 335	HS 454 FC	Full colour	(5.1	
450	HS 454 AG	Colour/gold dress rings	DIMENSIONAL	
Drawn left hand For ambulant disabilities			HYGIENIC SEAL® DIMENSIONAL COMPLIANT	
400 mm x 600 mm	Please specify	left or right hand		
, P T	HS 046 SS	Satin Supreme™	400 mm x 600 mm	
	HS 046 PS	Polish Supreme™	Stainless steel fixing screws supplied.	
	HS 046 KG	Diamond Shur-Grip®		
55, 600	HS 046 AC	Colour/chrome flange covers		
	HS 046 FC	Full colour		
65 335	HS 046 AG	Colour/gold dress rings	(HYGIENIC SEAL®)	
Drawn left hand			(HTGIENIC SEAL)	
600 mm x 600 mm	Please specify	left or right hand		
⋒ —	HS 606 SS	Satin Supreme™	600 mm x 600 mm	
	HS 606 PS	Polish Supreme™	Stainless steel fixing screws supplied.	
	HS 606 KG	Diamond Shur-Grip®		
600	HS 606 AC	Colour/chrome flange covers		
55	HS 606 FC	Full colour		
265	HS 606 AG	Colour/gold dress rings		
335			(HYGIENIC SEAL®)	
Drawn left hand			(IT GIETHO SELE)	
960 mm x 600 mm	Please specify	left or right hand		
	HS 966 SS	Satin Supreme™	960 mm x 600 mm	
	HS 966 PS	Polish Supreme™	Complies with requirements of AS 1428.1-2009 for water closets.	
	HS 966 KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.	
55	HS 966 AC	Colour/chrome flange covers		
	HS 966 FC	Full colour	AS 1428.1	
	HS 966 AG	Colour/gold dress rings		
625	110 000 710	oorean, gera areee ringe	D\	
960 335			HYGIENIC SEAL® DIMENSIONAL COMPLIANT	
Drawn left hand 1030 mm x 600 mm	Diago en estr	loft or right hand	SONI ELITT	
1030 IIIII X 600 IIIII		left or right hand	1000	
₽ ⊤	HS 106 SS	Satin Supreme™	1030 mm x 600 mm Complies with requirements of	
 	HS 106 PS	Polish Supreme™	AS 1428.1-2009 for water closets.	
- S5. 600	HS 106 KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.	
	HS 106 AC	Colour/chrome flange covers		
	HS 106 FC	Full colour		
695	HS 106 AG	Colour/gold dress rings	AS 1428.1	
1030 335				
			DIMENSIONAL	
Note: Horizontal flange			HYGIENIC SEAL® COMPLIANT	
Drawn left hand connects directly to rear wall. 1110 mm x 1030 mm x 600 mm	Please specify	left or right hand		
- 1110 mm x 1000 mm x 000 mm -			1110 mm x 1030 mm x 600 mm	
■	HS 116 SS	Satin Supreme™	centre to wall corner	
^ ⊤	110 440 00	Dallah O TM		
[HS 116 PS	Polish Supreme™	Complies with requirements of	
600	HS 116 KG	Diamond Shur-Grip®	Complies with requirements of AS 1428.1-2009 for water closets.	
55			Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.	
556	HS 116 KG	Diamond Shur-Grip®	Complies with requirements of AS 1428.1-2009 for water closets.	
555 1110 177 524 1030 335	HS 116 KG HS 116 AC	Diamond Shur-Grip® Colour/chrome flange covers	Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.	

(HYGIENIC SEAL®)



PREMIUM - CORNER GRAB RAILS

HYGIENIC SEAL® Safe-Assist® 32 mm grab rails. Fabricated from 304 stainless steel and assembled with 50 mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The HYGIENIC SEAL® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800 mm to 810 mm above floor level.

00 mm x 600 mm	Code Please spec	Finish ify left or right hand	Features
	HS 660 SS	Satin Supreme™	MADE TO ORDER NON-RETURNABLE
	HS 660 PS	Polish Supreme™	
I	HS 660 KG	Diamond Shur-Grip®	600 mm x 600 mm centre to wall corner
55 55	HS 660 AC	Colour/chrome flange covers	Stainless steel fixing screws supplied.
177	HS 660 FC	Full colour	
600	HS 660 AG	Colour/gold dress rings	
	110 000 Ad	Joiour gold alcoo lillyo	
			LINGERIA OF AIR
awn left hand			(HYGIENIC SEAL [®])
00 mm x 700 mm		ify left or right hand	
	HS 770 SS	Satin Supreme™	MADE TO ORDER NON-RETURNABLE
1	HS 770 PS	Polish Supreme™	700 mm x 700 mm centre to wall corner
.55	HS 770 KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.
177	HS 770 AC	Colour/chrome flange covers	
700	HS 770 FC	Full colour	
/00	HS 770 AG	Colour/gold dress rings	
awn left hand			HYGIENIC SEAL®
50 mm x 750 mm	Please spec	ify left or right hand	
	HS 757 SS	Satin Supreme™	MADE TO ORDER NON-RETURNABLE
I	HS 757 PS	Polish Supreme™	
.55	HS 757 KG	Diamond Shur-Grip®	750 mm x 750 mm centre to wall corner Stainless steel fixing screws supplied.
177	HS 757 AC	Colour/chrome flange covers	otannoss stool namy sciews supplied.
750	HS 757 FC	Full colour	
/50	HS 757 AG	Colour/gold dress rings	
	4		
rawn left hand			HYGIENIC SEAL®
00 mm x 800 mm		ify left or right hand	MADE TO ODDER HOW DETURNING
	HS 880 SS	Satin Supreme™	MADE TO ORDER NON-RETURNABLE
1	HS 880 PS	Polish Supreme™	800 mm x 800 mm centre to wall corner
	HS 880 KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.
55	HS 880 AC	Colour/chrome flange covers	
	HS 880 FC	Full colour	
800			
800 629	HS 880 AG	Colour/gold dress rings	
800		Colour/gold dress rings	
800		Colour/gold dress rings	
		Colour/gold dress rings	HYGIENIC SEAL®
awn left hand	HS 880 AG		HYGIENIC SEAL®
awn left hand	HS 880 AG	Colour/gold dress rings ify left or right hand Satin Supreme™	760 mm x 1000 mm centre to wall corner
rawn left hand	HS 880 AG	ify left or right hand	
awn left hand	HS 880 AG Please spec HS 761 SS	ify left or right hand Satin Supreme™	760 mm x 1000 mm centre to wall corner
rawn left hand 60 mm x 1000 mm	Please spec HS 761 SS HS 761 PS	ify left or right hand Satin Supreme™ Polish Supreme™	760 mm x 1000 mm centre to wall corner
rawn left hand 60 mm x 1000 mm	Please spec HS 761 SS HS 761 PS HS 761 KG	ify left or right hand Satin Supreme™ Polish Supreme™ Diamond Shur-Grip®	760 mm x 1000 mm centre to wall corner
rawn left hand 60 mm x 1000 mm	Please spec HS 761 SS HS 761 PS HS 761 KG HS 761 AC	ify left or right hand Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Colour/chrome flange covers	760 mm x 1000 mm centre to wall corner
awn left hand 60 mm x 1000 mm	Please spec HS 761 SS HS 761 PS HS 761 KG HS 761 AC HS 761 FC	ify left or right hand Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Colour/chrome flange covers Full colour	760 mm x 1000 mm centre to wall corner
awn left hand 50 mm x 1000 mm	Please spec HS 761 SS HS 761 PS HS 761 KG HS 761 AC HS 761 FC	ify left or right hand Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® Colour/chrome flange covers Full colour	760 mm x 1000 mm centre to wall corner




PREMIUM - SHOWER RECESS GRAB RAILS

March Hygienic Seal® Safe-Assist® 32 mm grab rails. Fabricated from 304 stainless steel and assembled to the rail wall and prevent the accumulation of unhealthy grime. The HYGIENIC SEAL® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800 mm

with 50 mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to 810 mm above floor level.





Optional extra: SD 032 Soap Dish

Please specify le	ft or right hand
HS 041 SS	Satin Supreme™
HS 041 PS	Polish Supreme™
HS 041 KG	Diamond Shur-Grip®
HS 041 AC	Colour/chrome flange covers
HS 041 FC	Full colour
HS 041 AG	Colour/gold dress rings

Finish

Code

MADE TO ORDER NON-RETURNABLE

400 mm x 1100 mm "L" shape grab rail. Stainless steel fixing screws supplied.



Features

1100 1100 1100 Centre Drawn left hand Drawn right hand

		<u> </u>
HS 071	SS	Satin Supreme™
HS 071	PS	Polish Supreme™
HS 071	KG	Diamond Shur-Grip®
HS 071	AC	Colour/chrome flange covers
HS 071	FC	Full colour
HS 071	AG	Colour/gold dress rings

Please specify left or right or centre fix


TO SUIT SINGLE ACCESSIBLE SHOWER RECESS

700 mm x 1100 mm Inverted "T" grab rail. Left and right hand models only comply with AS 1428.1-2009 for a 2 walled shower enclosure.

Stainless steel fixing screws supplied.







HS 191 SS	Satin Supreme™
HS 191 PS	Polish Supreme™
HS 191 KG	Diamond Shur-Grip®
HS 191 AC	Colour/chrome flange covers
HS 191 FC	Full colour
HS 191 AG	Colour/gold dress rings

Please specify left or right hand

TO SUIT COMBINED ACCESSIBLE SANITARY COMPARTMENT

1170 mm x 1100 mm Inverted "T" grab rail. Complies with requirements of AS 1428.1-2009 for a 2 walled shower enclosure. Stainless steel fixing screws supplied.





760 mn	n x 1000 mm x 1100 mm SHOWER RECESS
1100	1100 829 1700 Drawn right hand
180	760 1000 1000 1000 1000 1000 1000 1000 1
	Orawn left hand

Please	specify le	ft or right hand
HS 711	SS	Satin Supreme™
HS 711	PS	Polish Supreme™
HS 711	KG	Diamond Shur-Grip®
HS 711	AC	Colour/chrome flange covers
HS 711	FC	Full Colour
HS 711	AG	Colour/gold dress rings

TO SUIT CORNER SHOWER RECESS

760 mm x 1000 mm x 1100 mm centre to wall corner grab rail.

Stainless steel fixing screws supplied.





PREMIUM - GRAB RAIL WITH TOWEL RAIL

HYGIENIC SEAL® Safe-Assist 32 mm grab rail with 19 mm towel rail. Fabricated from 304 stainless steel and assembled with 50 mm brass screw on flange covers with Thermoplastic Elastometer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The HYGIENIC SEAL® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800 mm to 810 mm above floor level.



	Code	Finish	Features
600 mm x 19 mm "D" SHAPE	HS 619 SS HS 619 PS	Satin Supreme™ Polish Supreme™	Towel rail 19 mm Overall width - 650 mm Overall depth - 161 mm Stainless steel fixing screws supplied.
800 mm x 19 mm "D" SHAPE			HYGIENIC SEAL®
900	HS 819 SS HS 819 PS	Satin Supreme™ Polish Supreme™	 800 mm "D" shape Ø to Ø Towel rail 19 mm Overall width - 850 mm Overall depth - 161 mm Stainless steel fixing screws supplied.
1000 mm x 19 mm "D" SHAPE			HYGIENIC SEAL®
1000 mm x 19 mm "D" SHAPE	HS 109 SS HS 109 PS	Satin Supreme™ Polish Supreme™	1000 mm "D" shape Ø to Ø • Towel rail 19 mm • Overall width - 1050 mm • Overall depth - 161 mm • Stainless steel fixing screws supplied.
1200 mm x 19 mm "D" SHAPE			HYGIENIC SEAL®
1200	HS 129 SS HS 129 PS	Satin Supreme™ Polish Supreme™	1200 mm "D" shape ∅ to ∅ • Towel rail 19 mm • Overall width - 1250 mm • Overall depth - 161 mm • Stainless steel fixing screws supplied.
167 167 12 Con-Serv Grab Pail Manual			HYGIENIC SEAL®



PREMIUM - LINEAR GRAB RAIL OPTIONS

LINEAR style Safe-Assist® 32 mm grab rails and shower kits. Fabricated from 304 stainless steel and assembled with 50 mm brass screw on "T" leg LINEAR flange with fitted seals which prevent the accumulation of unhealthy grime. The LINEAR grab rails comply with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800 mm to 810 mm above the floor.



	Code	Finish	Features
STRAIGHT GRAB RAILS			
310	LR 200 SS	Satin Supreme [™]	200 mm Ø to Ø - Straight grab rail
200	LR 200 PS	Polish Supreme™	300 mm Ø to Ø - Straight grab rail
410	LR 300 SS	Satin Supreme [™]	450 mm Ø to Ø - Straight grab rail
300	LR 300 PS	Polish Supreme™	600 mm Ø to Ø - Straight grab rail
560	LR 450 SS	Satin Supreme™	900 mm Ø to Ø - Straight grab rail
450	LR 450 PS	Polish Supreme™	Add 55 mm for each capped extension.
710	LR 600 SS	Satin Supreme™	Stainless steel fixing screws supplied.
600	LR 600 PS	Polish Supreme [™]	
1010	LR 900 SS	Satin Supreme™	LINEAD
	LR 900 PS	Polish Supreme™	LINEAR
870 mm x 700 mm TOILET ASSIST GRAB RAIL		eft or right hand	
1406	LR 877 LH SS	Satin Supreme™	870 mm x 700 mm - Toilet assist grab rail Add 55 mm for each capped extension.
T	LR 877 RH SS	Satin Supreme [™]	Complies with requirements of AS 1428.1-2009 for water
55 100 450	LR 877 LH PS	Polish Supreme™	closets. Stainless steel fixing screws supplied.
1	LR 877 RH PS	Polish Supreme™	
625 245	LITOTT THITTO	T Offort Suproffic	AS 1428.1
			(5)
			LINEAR DIMENSIONAL COMPLIANT
Drawn left hand			LINEAR COMPLIANT
960 mm x 600 mm TOILET ASSIST GRAB RAIL		eft or right hand	000 THE 1
L o	LR 966 LH SS LR 966 RH SS	Satin Supreme [™] Satin Supreme [™]	960 mm x 600 mm - Toilet assist grab rail Add 55 mm for each capped extension.
[]	LN 900 NH 33	Sauri Supreme	Complies with requirements of AS 1428.1-2009 for water
600	LR 966 LH PS	Polish Supreme™	closets. Stainless steel fixing screws supplied.
55	LR 966 RH PS	Polish Supreme™	AS 1428.1
625			A3 1420.1
960 335			(b)
			LINEAR DIMENSIONAL COMPLIANT
Drawn left hand 450 mm x 450 mm AMBULANT TOILET ASSIST GRAB RAII	Please specify	eft or right band	
430 MIII X 430 MIII AMBOLANT TOLLET ASSIST UNAD NAI	LR 454 LH SS	Satin Supreme [™]	450 mm x 450 mm - Ambulant assist grab rail
l	LR 454 RH SS	Satin Supreme [™]	Add 55 mm for each capped extension. Complies with requirements of AS 1428.1-2009 for water
.6			closets.
55 450	LR 454 LH PS	Polish Supreme™	Stainless steel fixing screws supplied. AS 1428.1
	LR 454 RH PS	Polish Supreme™	AS 1420.1
450			(5)
Drawn left hand			LINEAR DIMENSIONAL COMPLIANT
LINEAR GRAB RAIL/SHOWER KIT			
ENTERIT GIRD HAIL/OHOWEIT KIT	LE 000 L C	Doliah CupromoTM	000 mm Polich SupremaTM steinless steel 204 grab rail with Praga



LF 900 J-C	Polish Supreme™

900 mm Polish Supreme™ stainless steel 304 grab rail with **Brass Friction Slide Cradle** for shower height adjustment. Also includes ABS Streamjet™ handpiece, PVC 1.5 m Silverflex® hose, soap dish and flow regulated wall outlet with licenced dual check. 3 Star - 9 L/min rated as per WELS licence number 0046. Complies

with requirements for a 2 walled shower enclosure when installed with HS 700 PS as per AS 1428.1-2009.






TILTLOCK® FOLDING RAIL-WAYS®

SAFE-ASSIST® folding grab rails for toilets and showers for use by persons who suffer from sickness or disablement. The TILTLOCK® automatically locks when in the horizontal position and locks vertically as a support grab rail for standing patients. Fabricated with a chromed brass button release base housing, a solid brass concealed 4 fix wall "T" mount bracket and 304 stainless steel tube.

The TILTLOCK® SAFE-ASSIST® folding grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Tested by ANTL, test report 2945.11.

GRAB RAILS SHOULD BE MOUNTED SO THAT THE TOP OF THE RAIL IS 800 mm TO 810 mm ABOVE THE FLOOR.





850 mm x 185 mm x 32 mm x dual bar folding grab rail with safety lock hinge mechanism. The TILTLOCK $^\circledR$ automatically locks when in the horizontal position and locks vertically out of the way when not required. Fabricated with a chromed solid brass concealed wall mount with four fixing points and chromed brass button release housing with 304 stainless steel tube, giving a most pleasing finish.

M8 x 75, stainless steel hexagon coach screws and 10 mm wall plugs supplied with Tiltlock®

Fitted with 304 stainless steel nurse call mount box. Nurse call switch not supplied with TILTLOCK®.

NO EXPOSED NUTS OR BOLTS Stainless steel fixing screws supplied.

120 F	94 Front view	94 Front view	MUST BE FITTED TO A SOLID WALL OR OTHER FIRM SURFACE.	
	PATE	ENT NUMBER: 2006100929	For other lengths, add \$5.00 per mm.	
	Code	Finish	Features	
850 mm TILTLOCK® GRAB RAIL	Please specify left	or right hand		
	TL 850 LH SS	Satin Supreme™	850 mm x 185 mm x 32 mm dual bar folding grab rail	
	TL 850 LH KG	Diamond Shur-Grip®	fabricated from 304 stainless steel with safety lock hinge mechanism. The TILTLOCK® with quick release automatically	
	TL 850 LH WT	White	locks when in horizontal position and locks vertically out of the way when not required.	
9				
	TL 850 RH SS	Satin Supreme™	NO EXPOSED NUTS OR BOLTS	
	TL 850 RH KG	Diamond Shur-Grip®	Stainless steel fixing screws supplied.	
	TL 850 RH WT	White		
Drawn left hand				
850 mm TILTLOCK® GRAB RAIL WITH	FLEXIBLE ABS TOILET ROLL H	IOLDER		
	TL 850T LH SS	Satin Supreme™	850 mm x 185 mm x 32 mm dual bar folding grab rail	
	TL 850T LH KG	Diamond Shur-Grip®	fabricated from 304 stainless steel with safety lock hinge mechanism. The TILTLOCK® with quick release automatically	
	TL 850T LH WT	White	locks when in horizontal position and locks vertically out of the	
			way when not required. Supplied with Flexible Fix ABS toilet roll holder fastened to grab rail.	
			·	
	TL 850T RH SS	Satin Supreme™	Supplied with Flexible ABS toilet roll holder fastened to grab rail.	
4	TL 850T RH KG	Diamond Shur-Grip®	•	
Flexible fix toilet roll holder - TR 031	TL 850T RH WT	White	NO EXPOSED NUTS OR BOLTS Stainless steel fixing screws supplied.	
Drawn left hand			otaliliess steel fixing serews supplied.	
850 mm TILTLOCK® GRAB RAIL WITH	SS FIXED TOILET ROLL HOLDI	ER		
	TL 850S LH SS	Satin Supreme™	850 mm x 185 mm x 32 mm dual bar folding grab rail	
	TL 850S LH KG	Diamond Shur-Grip®	fabricated from 304 stainless steel with safety lock hinge mechanism. The TILTLOCK® with quick release automatically	
	TL 850S LH WT	White	locks when in horizontal position and locks vertically out of the	
			way when not required.	
			Supplied with 19 mm stainless steel toilet roll holder	
The state of the s	TL 850S RH SS	·	secured to grab rail.	
	TL 850S RH KG	·	NO EXPOSED NUTS OR BOLTS	
	TL 850S RH WT	White	Stainless steel fixing screws supplied.	
Drawn left hand				
850 mm TILTLOCK® GRAB RAIL WITH				
	TL 850N LH SS	Satin Supreme™	850 mm x 185 mm x 32 mm dual bar folding grab rail fabricated from 304 stainless steel with safety lock hinge	
	TL 850N LH KG	Diamond Shur-Grip®	mechanism. The TILTLOCK® with quick release automatically	
	TL 850N LH WT	White	locks when in horizontal position and locks vertically out of the way when not required.	
			way when not required.	

Satin Supreme™

Diamond Shur-Grip®

TL 850N RH SS TL 850N RH KG

TL 850N RH WT White



SWINGLOCK® AND SIDE ASSIST RAIL-WAYS®


SAFE-ASSIST® dual bar, side swing grab rail for parallel cisterns and water closet designs when the toilet is installed in a corner requiring a grab rail each side of the pan. The SWINGLOCK® Hexagon F&M Lift/drop locking system eliminates bar sway, locks 45 degrees left or right hand and locks 90 degrees parallel with the wall when not required.




Optional extra: TR 031 Toilet roll holder

The SWINGLOCK® grab rails are in compliance with the general requirements for applications in hospitals, homes for the elderly and nursing homes. For water closest where the SWINGLOCK® is not suitable we recommend the TILTLOCK®.









CF 858 SS Satin Supreme™

850 mm x 805 mm free standing grab rail.
Fabricated from 304 stainless steel and assembled with 78 mm pre-formed domed CLAM FLANGE™.
Stainless steel fixing screws supplied.





SAFE-ASSIST® FOLDING SHOWER SEATS

SAFE-ASSIST® folding shower seats for persons who suffer from sickness or disablement. Seat frames with tension grip hinge for horizontal and vertical movement are fabricated from 304 stainless steel and secured to the seat deck with concealed 316 stainless steel screws. Seat decks feature tamperproof, sanitary safe, Polar White, UV stabilised, High Density Polyethylene (HDPE) round edge with self draining channels.

SHOWER SEATS SHOULD BE MOUNTED SO THAT THE SEAT DECK IS 470 mm to 480 mm ABOVE THE FLOOR.




Code Finish Features SEAT SIZE - 960 mm x 400 mm - SHOWER SEAT COMPLIES WITH THE MINIMUM DESIGN, STRENGTH AND DIMENSION REQUIREMENTS OF AS 1428.1-2009 Seat size: 960 mm x 400 mm SS 964 SS Satin Supreme™ Grade 304 stainless steel frame with Polar White High Density Polyethylene (HDPE) SS 964 PS Polish Supreme™ seat deck with self draining channels Complies with requirements of AS 1428. 1-2009 for a 2 walled shower enclosure. Stainless steel fixing screws supplied. MAX. LOAD: 160 Kg (25 stone) 480 Suits all standard accessible suites Wall Bracket Dimension SEAT SIZE - 960 mm x 400 mm - SHOWER SEAT COMPLIES WITH THE MINIMUM DESIGN, STRENGTH AND DIMENSION REQUIREMENTS OF AS 1428.1-2009 WHEELCHAIR TRANSFER SEAT. SS 964 WM Satin Supreme™ Seat size: 960 mm x 400 mm seat supported by heavy duty Tension Grip hinge brackets. Most suitable for convenient transfer between wheelchair and shower seat. Assembled with Polar White, UV stabilised, fade resistant,

WHEELCHAIR TRANSFER SEAT
Must be fitted to a solid wall or other firm

INSTALLATION HEIGHT OF SEAT: 470 mm - 480 mm

AS 1428.1

DIMENSIONAL COMPLIANT



Wall Bracket Dimension

SEAT SIZE - 960 mm x 400 mm - SHOWER SEAT COMPLIES WITH THE MINIMUM DESIGN, STRENGTH AND DIMENSION REQUIREMENTS OF AS 1428.1-2009



Designed for coved walls - Floor mounted

SS 964 CW Satin Supreme™

DESIGNED FOR BATHROOMS WITH COVED WALLS.

Complies with requirements of AS 1428.1-2009

for a 2 walled shower enclosure. Stainless steel fixing screws supplied MAX. LOAD: 160 Kg (25 stone)

Seat size: 960 mm x 400 mm seat with 100 mm x 60 mm coved plated rear legs for fixing to floor with 10 mm front leg Acetyl plugs to suit shower cubical gradient Assembled with Polar White, UV stabilised, fade resistant,

High Density Polyethylene (HDPE) seat deck with self draining channels.

High Density Polyethylene (HDPE) seat deck with self draining channels.

Complies with requirements of AS 1428.1-2009 for a 2 walled shower enclosure.

Stainless steel fixing screws supplied.

MAX. LOAD: 160 Kg (25 stone)





Floor Mount Dimension

SEAT SIZE - 960 mm x 400 mm - SHOWER SEAT COMPLIES WITH THE MINIMUM DESIGN, STRENGTH AND DIMENSION REQUIREMENTS OF AS 1428.1-2009



SS 964 MSS Stainless Steel
SS 964 MWT White

Seat size: 960 mm x 400 mm

Seat frame and 3 part slatted seat deck fabricated from 304 stainless steel.

Powder coated totally white.
Other colours available on request.

Other colours available on request.


Complies with requirements of AS 1428.1-2009 for a 2 walled shower enclosure.

Chainless shoul fiving assesses assessing

Stainless steel fixing screws supplied.

MAX. LOAD: 160 Kg (25 stone)





Wall Bracket Dimension

STANDARD FIXING - STUD WALLS

Use the 4 x stainless steel M8 x 75 mm coach screws supplied.

Fix seat with the coach screws into wall studs or nogging

Shower seats must be fitted to a solid wall or into stud construction.

Wall surface must be flat.

STANDARD FIXING - MASONRY WALLS

Use the 4 x stainless steel M8 x 75 mm coach screws and plugs supplied.

Fix seat with wall plugs and coach screws onto wall.

The installer should ensure that the nature of the wall will provide a firm fixing for all screws supporting the shower seat.



SAFE-ASSIST® PURPOSE BUILT SHOWER SEATS

SAFE-ASSIST® folding shower seats for persons who suffer from sickness or disablement. Seat frames with tension grip hinge for horizontal and vertical movement are fabricated from 304 stainless steel and secured to the seat deck with concealed 316 stainless steel screws. Seat decks feature tamperproof, sanitary safe, Polar White, UV stabilised, High Density Polyethylene (HDPE) round edge with self draining channels.

SHOWER SEATS SHOULD BE MOUNTED SO THAT THE SEAT DECK IS 470 mm to 480 mm ABOVE THE FLOOR.

Ŀ

Code Finish Features SEAT SIZE - 350 mm x 340 mm - FOR AREAS NOT STRICTLY DISABLED

White

Seat size: 350 mm wide by 340 mm deep fold-away ABS white slatted shower seat with strong aluminium support struts and wall fixing bracket. Designed to be fitted to a solid wall or other firm surface inside a shower cubicle or over a bath. Has many usages.

Stainless steel fixing screws supplied.

MAX. LOAD: 115 Kg (18 stone)

SEAT SIZE - 600 mm x 400 mm - FOR AREAS NOT STRICTLY DISABLED




SS 604 SS	Satin Supreme TM
SS 604 PS	Polish Supreme™
SS 604 MSS	Stainless Steel

Seat size: 600 mm x 400 mm Grade 304 stainless steel frame with Polar White High Density Polyethylene (HDPE) seat deck with self draining channels.

Stainless steel fixing screws supplied.


MAX. LOAD: 160 Kg (25 stone)



Wall Bracket Dimension

SEAT SIZE - 800 mm x 450 mm - MEETS NEW ZEALAND STANDARDS NZS 4121:2001

SS 220 WT




SS 845 SS	Satin Supreme™

Seat size: 800 mm x 450 mm Grade 304 stainless steel frame with Polar White High Density Polyethylene (HDPE) seat deck with self draining channels

Stainless steel fixing screws supplied.

MAX. LOAD: 160 Kg (25 stone)



SEAT SIZE - 960 mm x 500 mm - BARIATRIC SEAT FOR AREAS NOT STRICTLY DISABLED




Bariatric seat - Designed for heavier loads

SS 965 BS Satin Supreme™ LARGE SHOWER SEAT WITH ADDITIONAL CENTRE SUPPORT TO ACCEPT HEAVIER LOAD.

Seat size: 960 mm x 500 mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels.

Stainless steel fixing screws supplied

MAX. LOAD: 200 Kg (32 stone)



Wall Bracket Dimension

SEAT SIZE - 600 mm x 450 mm - SHOWER SEAT FOR LIMITED WALL AREAS NOT STRICTLY DISABLED



SS 645 SL Satin Supreme™ DESIGNED FOR OPPOSING WALL OPEN ENDED SHOWER ENCLOSURE AND SITUATIONS WHERE A WALL IS NOT WIDE ENOUGH TO ACCOMMODATE PRIOR ART FOLDABLE SEATS.

Seat size: Side lift, 600 mm x 450 mm shower seat, assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels.

Stainless steel fixing screws supplied.

MAX. LOAD: 160 Kg (25 stone)



Wall Bracket Dimension

STANDARD FIXING - STUD WALLS

Seat lifts side ways to wall Patent Number: 2008100882

Use the 4 x stainless steel M8 x 75 mm coach screws supplied. Fix seat with the coach screws into wall studs or nogging Shower seats must be fitted to a solid wall or into stud construction Wall surface must be flat

STANDARD FIXING - MASONRY WALLS

Use the 4 x stainless steel M8 x 75 mm coach screws and plugs supplied.

Fix seat with wall plugs and coach screws onto wall.

The installer should ensure that the nature of the wall will provide a firm fixing for all screws supporting the shower seat.



Safe-Assist® BACKREST for Healthcare Applications

The BACKREST, a support device for toilets, bidets and the like, introduced into the Australian Standard for Access and Mobility to comply with the changing requirements for sanitary facilities.

The BACKREST provides a support that improves the comfort of using a toilet while simultaneously providing an acceptable level of safety for disabled, aged and infirmed.

Con-Serv® patented BACKREST options as shown are compatible with all cisterns. But due to the different dimensions in cistern design, it is essential to select the correct BACKREST option to comply with the Australian Access and Mobility Standard AS 1428.1-2009 for single (Figure 52 of AS 1428.1-

2009) or combined (Figure 50 of AS 1428.1-2009) sanitary compartments.

Tested by the Australian National Testing Laboratories Pty Ltd (ANTL) as outlined in clause 15.2.4 BACKREST of AS 1428.1-2009, careful selection from the Con-Serv® Safe-Assist® BACKREST range will ensure full compliance with the Australian Standards requirement. Floor mount BACKREST test report -3104.11 and Wall Mount BACKREST test report - 3411.11

For further information, refer to the BACKREST Suitability Guide or contact our Technical Product Adviser on the Priority Phone Number - 1300 467 322.

Safe-Assist® BACKREST Options



Suits all standard accessible suites. Ideally suited to applications when fastening to rear wall is not an option. E.g. vinyl walls or insufficient bracing.



Adjusts to suit cisterns from 340 mm to 476 mm width, while still allowing the unimpeded installation and access to other grab rails at side of pan as per requirements of AS 1428.1-2009 (fig 42).



Flexible installation left or right side of cisterns from 340 mm to 476 mm width and includes an additional 400 mm grab rail extension as per requirements of AS 1428.1-2009 (fig 42).

SUITABILITY GUIDE	BR 395	BR 400	BR 440
Sanitary Compartment with Conventional Pan	•	•	•
Sanitary Compartment with Wall Faced Pan		•	•
Sanitary Compartment with Shower and Conventional Pan	•	•	
Sanitary Compartment with Shower and Wall Faced Pan		•	


SAFE-ASSIST® - BACKREST



SAFE-ASSIST® BACKREST support for single toilet suites and combined PWD sanitary compartments.

Robust designed 32 mm grade 304 stainless steel Backrest. Fabricated with a choice of 78 mm domed CLAM FLANGE™ or 50 mm HYGIENIC SEAL® healthsafe flange cover. The Backrest features a 96° tamperproof, sanitary safe, Polar White, UV stabilised High Density Polyethylene (HDPE)

rounded edge back support.








HYGIENIC SEAL®

BR 400 HS SS Satin Supreme™ BR 400 HS PS Polish Supreme™



BR 440 - WALL MOUNTED BACKREST WITH 400 mm EXTENSION








CLAM FLANGE™

BR 440 CF SS Satin Supreme™ BR 440 CF PS Polish Supreme™

HYGIENIC SEAL®

BR 440 HS SS Satin Supreme™ BR 440 HS PS Polish Supreme™


- For single PWD cubicle with conventional pan.
- For single PWD cubicle with wall faced pan.
- The adjustable 400 mm extended mount can be installed on the left or right hand side of cistern.
- · Stainless steel fixing screws supplied





Safe-Assist® ANTI-LIGATURE GRAB RAILS Bars for High Risk Applications

Specially designed 38 mm Anti-Ligature grab rails with barrier manufactured from grade 304 stainless steel for use in water closets and other assist requirement areas to eliminate the possibility of self harm by patients or inmates in psychiatric clinics, hospitals and detention facilities.





SAFE-ASSIST® ANTI-LIGATURE GRAB RAILS

Specially designed 38 mm toilet assist Anti-Ligature grab rails with combined vertical and horizontal barriers, manufactured from 304 stainless steel for use in water closets with concealed or exposed cisterns to eliminate the possibility of self harm by patients or inmates in psychiatric clinics, hospitals and detention facilities.

Generally meets the requirements of AS 1428.1-2009.





CIRCULATION SPACE & POSITION OF GRAB RAILS IN WATER CLOSETS



FIGURE 43 - CIRCULATION SPACE FOR WC PAN - RIGH	IT HAND TRANSFER (LEFT HAND TRANSFER IS MIRROR REVERSED)	
	THE THE THE MEDICAL CONTRACT OF THE MEDICAL CONTRACT O	
Plan		
	Due to live action and total and Orac	
	Due to licensing restrictions Con-Serv	
	is unable to provide this information in	
	a digital version. For a printed version	
	please contact us.	
LEGEND:		
Circulation space		
FIGURE 42 - POSITIONS OF GRAB RAILS IN WATER CL	nsets	
	USLIS	
Elevation		
	Due to licensing restrictions Con-Serv	
	is unable to provide this information in	
	a digital version. For a printed version	
	a uigitai versioni. Foi a printeu versioni	
	please contact us.	




SIDE VIEW SHOWING OPTIONAL SYSTEMS

FOR GRAB RAILS AT SIDE OF PAN

Horizontal grab rails should be mounted so that the top of the rail is 800 mm to 810 mm above the floor level. Rails fitted with CLAM FLANGE™ or HYGIENIC SEAL® on request. Toilet assist grab rails in this section comply strictly with the minimum design, strength and dimension requirements of AS 1428.1-2009. _____

Complies as per requirements of AS 1428.1-2009 section 15.2.6, figure 41, ZONE FOR THE POSITION OF TOILET PAPER DISPENSER.



Drawn right hand

Drawing not to scale

Drawn right hand

Drawing not to scale.



SYSTEMS FOR PEOPLE WITH DISABILITIES (PWD)

2 WALLED SHOWER ENCLOSURE


Grab rails, Shower support rails and the Shower seat in this section comply strictly with the minimum design, strength and dimension requirements of AS 1428.1-2009, Design for Access and Mobility. Shower seats should be mounted so that the top of the seat is 470 mm to 480 mm above the floor.

Mount horizontal section of rail 800 mm to 810 mm above floor level.

FIGURE 47 - SHOWER RECESS CIRCULATION SPACE

Plan

Due to licensing restrictions Con-Serv is unable to provide this information in a digital version. For a printed version please contact us.





LEGEND:

Circulation space

FIGURE 48 - SHOWER RECESS FITTINGS

Elevation

Due to licensing restrictions Con-Serv is unable to provide this information in a digital version. For a printed version please contact us.



Drawn right hand

OPTIONS FOR USE IN 2 WALLED SHOWER ENCLOSURE

WaterMark AS/NZS 3662 WMKT 21147

3 STAR - 9 L/min as per WELS licence number - 0046. Horizontal grab rails should be mounted so that the top of the rail is 800 mm to 810 mm above the floor level. Rails fitted with HYGIENIC SEAL® flange.

Description

Code

OPTION A ID 018-3 INDEPENDENT HOSFAB® - PWD ID 018 KIT 3 • Independent accessible 1000 mm handheld shower/grab rail combination with PUSH-PULLME® showerhead height AND adjustment rod for seated persons. • Requires an additional 700 mm grab rail, 1 x HS 700 SS • The PUSH-PULLME® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000 mm and 1800 mm above the floor and 1000 allows access and adjustment from a seated position. • Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD) · Licenced dual check/non-return valve. Brass Friction Slide Cradle with Push-PullMe® INDICATIVE IMAGE ONLY (Refer to page 54, figure 48 for recommended positioning) 9 HYGIENIC SEAL® Lic. no. 0046 OPTION B ID 020-L INDEPENDENT HOSFAB® - PWD LEFT HAND • Independent accessible 700 mm x 1100 mm, LEFT HAND ID 018 KIT 20L inverted "T" handheld shower/grab rail combination with PUSH-PULLME® showerhead, height adjustment rod for seated persons. • The PUSH-PULLME® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000 mm and 1800 mm above the floor and allows access and adjustment from a seated position. • Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD) 1100 · Licenced dual check/non-return valve. Brass Friction INDICATIVE IMAGE ONLY Slide Cradle with (Refer to page 54, figure 48 for Push-PullMe® recommended positioning) WATER RATING 495 700 HYGIENIC SEAL® Drawn left hand Lic. no. 0046 OPTION C ID 020-R INDEPENDENT HOSFAB® - PWD RIGHT HAND ID 018 KIT 20R • Independent accessible 700 mm x 1100 mm, RIGHT HAND inverted "T" handheld shower/grab rail combination with PUSH-PULLME® showerhead, height adjustment rod for seated persons. • The PUSH-PULLME® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000 mm and 1800 mm above the floor and allows access and adjustment from a seated position. Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD). Licenced dual check/non-return valve. 1100 Brass Friction Slide Cradle with Push-PullMe^o INDICATIVE IMAGE ONLY (Refer to page 54, figure 48 for recommended positioning) 9

Lic. no. 0046

HYGIENIC SEAL®



SYSTEMS FOR PEOPLE WITH DISABILITIES (PWD)

TO SUIT COMBINED ACCESSIBLE SANITARY COMPARTMENT

Grab rails, shower support rails and the shower seat in this section comply strictly with the minimum design, strength and dimension requirements of AS 1428.1-2009, Design for Access and Mobility. Shower seats should be mounted so that the top of the seat is 470 mm to 480 mm above the floor. Mount horizontal section of

rail 800 mm to 810 mm above floor level.

FIGURE 50 - SHOWER RECESS CIRCULATION SPACE

Plan

Due to licensing restrictions Con-Serv is unable to provide this information in a digital version. For a printed version please contact us.






FIGURE 50 - SHOWER RECESS ELEVATION

Elevation

Due to licensing restrictions Con-Serv is unable to provide this information in a digital version. For a printed version please contact us.



OPTIONS FOR USE TO SUIT

COMBINED ACCESSIBLE SANITARY COMPARTMENT

3 STAR - 9 L/min as per WELS licence number - 0046. Horizontal grab rails should be mounted so that the top of the rail is 800 mm to 810 mm above the floor level. Rails fitted with HYGIENIC SEAL® flange. ▲

Code Description



Brass Friction Slide Cradle with Push-PullMe®

OPTION A ID 018-3 INDEPENDENT HOSFAB® - PWD

ID 018 KIT 3
 AND
 Independent accessible 1000 mm handheld shower/grab rail combination to suit Combined Accessible Sanitary Compartment with PUSH-PULLME® shower head height adjustment rod for seated persons.

• Requires an additional 1200 mm grab rail.

- The PUSH-PULLME® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000 mm and 1800 mm above the floor and allows access and adjustment from a seated position.
- Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD).
- · Licenced dual check/non-return valve.


INDICATIVE IMAGE ONLY (Refer to page 56, figure 50 for recommended positioning)







OPTION B ID 018-21L INDEPENDENT HOSFAB® - PWD LEFT HAND



ID 018 KIT 21L • Independent acces inverted "T" handh-

ID 018 KIT 21R

- Independent accessible 1170 mm x 1100 mm, LEFT HAND inverted "T" handheld shower/grab rail combination to suit Combined Accessible Sanitary Compartment with PUSH-PULLME® shower head height adjustment rod for seated persons.
- The PUSH-PULLME® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000 mm and 1800 mm above the floor and allows access and adjustment from a seated position.
- Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD).
- Licenced dual check/non-return valve.


INDICATIVE IMAGE ONLY (Refer to page 56, figure 50 for recommended positioning)







OPTION C ID 018-21R INDEPENDENT HOSFAB® - PWD RIGHT HAND



- Independent accessible 1170 mm x 1100 mm, RIGHT HAND inverted "T" handheld shower/grab rail combination to suit Combined Accessible Sanitary Compartment with PUSH-PULLME® shower head height adjustment rod for seated persons.
- The PUSH-PULLME® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000 mm and 1800 mm above the floor and allows access and adjustment from a seated position.
- Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD).
- Licenced dual check/non-return valve.

INDICATIVE IMAGE ONLY (Refer to page 56, figure 50 for recommended positioning)





















About Stainless Steel **Grab Rails**

Alloy Types

304 is the basic chromium-nickel austenitic stainless steel and has been found suitable for a wide range of applications. It is the most readily available in a variety of product forms. This grade is easy to form and fabricate and is resistant to corrosion.

304L is the low carbon version of 304. The use of the letter "L" after the grade number means that the carbon content is restricted to a maximum of 0.03% (normal levels are 0.08%). The lower level of carbon is usually used where welding is performed and helps to prevent the chromium from being depleted so it can form the "passive" oxide layer, giving excellent resistance to corrosion and metallurgically incapable of rusting.

316 offers more corrosion-resistance through the addition of molybdenum, this grade is desirable where the possibility of severe corrosion exists, such as marine environments.

316L is the low carbon version of 316.

What Does 18/8 Mean

The first number is the amount of chromium that is contained in the stainless. The second number is the amount of nickel. So 18/8 means that this stainless steel contains 18% chromium and 8% nickel and is part of the grade family "300 series" stainless which is non-magnetic.

Care of Stainless Steel

To have an optimum corrosion resistant stainless steel, surfaces must be clean and have an adequate supply of oxygen to maintain their 'passive' surface layer. Passive Film is invisible in stainless steel. It's created when oxygen combines with chromium in the stainless to form chromium oxide.

Stainless steel supplied by reputable manufacturers or fabricators will normally be clean and contamination free. Generally, stubborn stains and discolouration corrosion

occurs when there is an overall breakdown of the 'passive' film, due to incorrect cleaning procedures. Rust staining can occur as anything from a slight brown 'bloom' on the surface to severe surface pitting or rusty scour marks on items such as GRAB RAILS and HAND RAILS. Cleanliness and stainless steel are closely related in many applications and each is dependent upon the other. Cleanliness is essential for maximum resistance to corrosion.

The Cleaning of Stainless Steel

Alkali cleaners such as baking soda or ammonia are effective to clean stainless steel. Always attempt the mildest cleaning method first. Stainless steel's best friends are quite simply soap, mild detergent or ammonia solution in warm water applied with a soft cloth or nylon sponge for polished finishes followed by a clean water rinse. Dry wipe eliminates the possibility of water stains. Occasionally, the use of the least coarse nylon scouring pad may be required for satin finishes.

What to Avoid

Do not use ordinary steel wool. Iron particles can become embedded in stainless steel and cause 'iron' contamination.

Do not use chlorides or acids as they are reactive to stainless steel. Strong acid solutions like hydrochloric acid or "spirit of salts" are sometimes used to clean masonry and tiling of new bathrooms and toilets, but they should NEVER be permitted to come into contact with metals, INCLUDING STAINLESS STEEL.

Halogen salts, especially chlorides easily penetrate the "passive film" of stainless steel and will allow corrosive attack to occur. The halogens are easy to recognize because they end in the letters "INE". Listed in order of their activity are:

- Fluorine
- Chlorine
- Bromine
- lodine
- Astatine

Never use brick cleaning liquids which contain hydrochloric acid. Many cleaning solutions and solvents contain chlorinated hydrocarbons. If a cleaner containing chlorides, bleaches and hypochlorites are used, it must be promptly and thoroughly cleaned off.

Please note: The Con-Serv warranty on grab rails will be null and void should they be exposed to chemical corrosion due to incompetent cleaning practices.



grab rail manual



Protecting the world's most valuable liquid asset... water!



CON-SERV CORPORATION AUSTRALIA PTY. LTD.

17 Glentanna Street, Kedron \cdot Qld. 4031 Australia Phone: +61 (0)7 3630 5744 \cdot Fax: +61 (0)7 3630 5755 E-mail: mail@con-serv.com.au \cdot www.con-serv.com.au